

Total Energy Controls



TEC 1750 Programming &
Installation Manual

Contents

Description	Page
Installation Instructions	
General Notes	3
Mains Wiring	3
Control Wiring	4
Fitting and Wiring Temperature Sensors	5
Commissioning Instructions	
Introduction	7
Keypad Overview	7
The Display	9
Setting the Optimisation	10
Setting the Programs	11
Setting the Calendar	11
Programming the On / Off Times	13
Frequency (How the Time Clock works)	15
Select Days	16
Optimise On Time	17
Optimise Off Time	18
Setting the Day Temperature	19
Setting the Night Temperature	20
Setting the Maximum Duct Temperature	21
Setting the Minimum Duct Temperature	22
Setting the On Time (Cycling Mode)	23
Setting the Off Time (Cycling Mode)	24
View External Temperature	25
Calibration	26
Exiting Programming Mode	28

Installation

General Notes

The installation of all TEC units should be carried out by a qualified electrical engineer familiar with heating systems and control wiring.

All control circuits of TEC units are 'volt free' and may be used to switch 240V AC or low voltage control systems.

Extreme care must be taken to ensure that all wiring is correct before applying power, as non-repairable damage to the PCB could result due to incorrect connections.

Mains Wiring

Unscrew the four screws of the TEC 1750 and remove the lid to gain access to the PCB and wiring connections.

A 240V AC 1Ph 50Hz supply may be taken from the existing time clock switched or permanent supply, or direct from the boiler mains input connections (where available), whichever is the most suitable. The 240V connection to the TEC 1750 is shown in Fig.1 below.




Fig. 1

Control Wiring

NOTE: If a wiring harness is provided in the rear of the enclosure please follow cables to TEC 1750 PCB to determine connections as described in the following sections.




Fig. 2

Note: A 5-core heat resistant flex is ideal for connecting the TEC 1750 to the heater. The recommended connection method is via a flexible nylon conduit to house the cable.

Fitting and Wiring Temperature Sensors

The TEC 1750 has three temperature sensor inputs, these being **Duct**, **Internal** and **External** (optional). Connections are as shown in Fig.5.




Fig. 5

Internal Temperature Sensor

The INTERNAL sensor can be fitted adjacent to the existing Room Thermostat if this is considered to be installed in a satisfactory location. Alternatively, the sensor may be located in the return path of the heater itself. In many instances, this may be the most convenient place to install. See Fig.6.




Fig. 6

Duct Temperature Sensor

In the case of a free standing warm air heater the DUCT sensor should be installed into one of the duct outlets, ensuring that the sensor picks up a positive flow of hot air that is not shielded by any of the air deflectors. On a fully ducted warm air heating system the sensor should be installed into the ducting, as close to the heater as possible.

Care must be taken that the sensor does not detect any excessive temperature rise created by the heater before the heater fan switches on.

External Sensor (Optional)

The **External Sensor** should preferably be positioned on a north facing exterior wall, and connected to the appropriate terminals of the TEC 1750. If it is not possible to mount the sensor on a north facing wall, then mount in a shaded position, under eaves, and away from boiler house vent grilles etc.

Commissioning - Introduction

The TEC 1750 Digital has 14 main programs, these being:

- | | | |
|---|--|--|
| <ol style="list-style-type: none"> 1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. | <ul style="list-style-type: none"> Calendar On/Off Times Frequency Select Days Optimise On Time Optimise Off Time Set Day Temperature Set Night Temperature Maximum Duct Temperature Minimum Duct Temperature Set On Time (Cycling Mode) Set Off Time (Cycling Mode) View External Temperature Calibrate | <ul style="list-style-type: none"> (Two On/Off Periods per day) (Once, Twice, 24 Hours) (Every Day, Weekends, Week Days) (0 to 240 minutes) (0 to 240 minutes) (0°C to 30 °C) (0°C to 30°C) (50°C to 85°C) (50°C to 85°C) (1 to 15 minutes) (1 to 15 minutes) |
|---|--|--|

Keypad and Running Mode Overview




PROGRAM

Used to enter Programming Mode from normal running mode, and to access Change Mode for the selected program.



SELECT

Used to cycle through the program list when in Programming Mode and to change program settings when in Change Mode.



RETURN


Used to cycle through the program list when in Programming Mode and to change program settings when in Change Mode.



ENTER


Used to confirm a programming change and to exit from the Programming Mode.

Firing mode indicates that the heater is firing.




```
FIRING Mo 10:12
DT 70/60 T 65 D
```

Temp Set indicates that the **programmed day/night temperature** has been achieved. The heater will not be firing at this point.



```
TEMPERATURE SET
DT 70/60 T 65 D
```


Economy indicates that the TEC 1750 is making economies. The heater will **not** be firing at this point.




```
ECONOMY
DT 70/60 T 65 D
```

The Display


1. Switch on the power to the TEC 1750.
2. The display will show:



3. Pressing the



RETURN



Setting the Optimisation

The maximum optimisation (preheat) for Winter conditions (external temperature $< -1^{\circ}\text{C}$) may be determined by the historic settings of the existing time clock or if in doubt discuss with the owner/occupier/manager of the building to which the installation applies. In most warm air installations this will be 1-2 hours. If the external sensor is not used, add 15 minutes to the normal maximum preheat.

Set the optimisation time using program 5 as described later in this manual.

The TEC 1750 will automatically reduce the maximum preheat depending on the internal temperature at time clock switch on time. If the external sensor is fitted the ultimate preheat period will be derived from the combined input of both sensors. The preheat search period will occur each time the time clock is activated.

If a second off period is selected the on time must be compensated to allow for the optimisation search period that will occur.















I.E. First on period 07.00, maximum preheat of 1 hour to allow for an 08.00 occupation time. If the second on/off period is 13.00 to 15.00 then set the time clock to 13.00 OFF, 14.00 ON, therefore making the second on time 1 hour before that required.















This is to allow for the fact as the space temperature will be at normal levels, the TEC 1750 will delay the switch on time by 1 hour (in this example).

The use of a second on/off period is not always the most economical way to run a warm air heating system. To avoid the complications of the optimiser as described it may be better to persuade the user to use only one on/off period.

Setting the Programs

P1. Setting the Calendar (Factory Set)

1. Press  to change display to: 
2. Press  again to display: 
3. Press  or  to set the year.
4. Press  to change display to: 
5. Press  or  to set the month.
6. Press  to change display to: 
7. Press  or  to set the date.

8. Press  to change display to: 
9. Press  or  to set the hour.
8. Press  to change display to: 
9. Press  or  to set the minutes.
10. Press  to change display to: 
11. Press  or  to set the day.
12. Press  to confirm the program change and return to main menu.
13. Press  to advance to next program.
-

P2. Programming the Time Clock (On/Off Times)

If optimisation is not being used then set the ON time to provide the necessary pre-heat. If optimisation is selected then set the ON time to 15 minutes before the occupation time.

1. Press  or  to select program 2:

SELECT

RETURN



2 ON/OFF TIMES

2. Press  again to display:

PROGRAM




MO 1 07:30-00:00
2 00:00-16:30

There are two (2) programmable On/Off times per day.

The second OFF time must ALWAYS be programmed, and set to a time after, but in the same 24 hour period as the first ON time.


3. To change On/Off Times select the required day with




SELECT RETURN

4. Press  to enter programming mode for the chosen day:


PROGRAM



MO 1 07:30-00:00
* 2 00:00-16:30

5. Press  to set first ON time:

PROGRAM




SET HOUR
ON 1- 07:30

6. Press  or  to set the hour as required.

SELECT

RETURN

7. Press  to set first ON time minutes:




8. Press  or  to set the minutes as required.


9. Press  to set first OFF** time:



** If the FIRST OFF time is not required leave at 00:00.

Adjust HOUR and MINUTES in the same way as previously described.


10. Press  to set the second ON time and repeat as above.

11. Press  to set the second OFF time and repeat as above.



If different On/Off times are required for each day, then repeat the above instructions for each day's times.

To repeat a days On/Off times into the next day, select the next day as

described above and press  followed by  .

12. Press  to confirm program changes and return to main menu.

P3. Frequency (How the Time Clock operates)

1. Press  or  to select program 3:
 SELECT RETURN

3 FREQUENCY
CURRENT ONCE

2. Press  to display:
 PROGRAM

UP/DN TO CHANGE
CURRENT ONCE

3. Press  or  to set as described below:
 SELECT RETURN



ONCE The time clock operates from the first ON time to the second OFF time.

TWICE The time clock operates on both ON and OFF times i.e. two On/Off periods per day.

24 HOUR The time clock operates 24 hours a day regardless of the On/Off settings.

4. Press  to confirm program changes and return to main menu.
 ENTER
-

P4. Select Days

1. Press  or  to select program 4:
SELECT **RETURN**

4 SELECT DAYS
CURRENT EVERY DAY

2. Press  to display:
PROGRAM

UP/DN TO CHANGE
CURRENT EVERY DAY

3. Press  or  to set as described below:
SELECT **RETURN**

EVERY DAY


The heating will operate everyday as set by the time clock On/Off times.

WEEK ENDS

The heating will operate at week ends only as set by time clock On/Off time for Sat – Sun. If reduced heating is required at week ends then set the time clock for reduced hours during Saturday and Sunday, and then set program 4 to EVERY DAY.



WEEK DAYS

The heating will operate during week days only as set by the time clock On/Off times Mon – Fri. The heating will be OFF at weekends.

4. Press  to confirm program changes and return to main menu.
ENTER
-

P5. Optimise On

Set to match existing Pre-Heat times.

1. Press  or  to select program 5:
 SELECT RETURN

5 OPTIMISE ON
CURRENT 000 MINS

When programming a **Variable Pre-Heat** period (Optimum On) the first switch on time (P2) should be set to the buildings occupation time less 15 minutes. If a **variable pre-heat** period is **not** required, then the first switch on time must allow for a sufficient warm-up period before occupation time.



When selected, the full programmed **variable pre-heat** period will occur at 0°C external temperature. At temperatures above 0°C the system will calculate the required **pre-heat** time.


Note: To assure adequate temperatures are achieved by occupation time the maximum **pre-heat** period must satisfy the building's thermal characteristics.

If Optimum On is not required then set to 000 mins.



2. Press  to display:
PROGRAM

UP/DN TO CHANGE
CURRENT 000 MINS

3. Press  or  to set the required number of minutes.
SELECT RETURN

4. Press  to confirm program changes and return to main menu.
ENTER

P6. Optimise Off (for use with optional External Sensor)

1. Press  or  to select program 6:

↳ OPTIMISE OFF
CURRENT 000 MINS



Optimum Off periods will, when selected, switch off a boiler / heating system earlier than the programmed **off** time.


At 15°C external temperature the full **optimum off** period will occur and the heaters will switch off early. At 0°C external temperature there will be **no optimum off** and the boilers will switch off at the normal programmed time. At external temperatures between 0°C and 15°C the system will calculate the required **off** time.

If Optimum Off is not required (external sensor not fitted) then set to 000 mins.

2. Press  to display:









UP/DN TO CHANGE
CURRENT 000 MINS

3. Press  or  to set the required number of minutes.

4. Press  to confirm program changes and return to main menu.

P7. Day Temperature



Set to the space temperature (room) required during the normal ON periods.

1. Press  or  to select program 7:
SELECT **RETURN**

 2. Press  to change display to:
PROGRAM

 3. Press  or  to change the temperature setting to that required (i.e. 21°C).
SELECT **RETURN**
 4. Press  to confirm the program changes and return to main menu.
ENTER
-


P8. Night Temperature

Set to the space temperature (room) required during the normal OFF periods.



If a night temperature is not required then set to 0°C.


1. Press  or  to select program 8:
SELECT RETURN

8 SET NIGHT TEMP
 CURRENT 10.0

 2. Press  to change display to: PROGRAM

UP/DN TO CHANGE
 CURRENT 11.0

 3. Press  or  to change the temperature setting to that required.
SELECT RETURN



 4. Press  to confirm the program changes and return to main menu.
ENTER
-

P9. Maximum Duct Temperature

Applicable when the Duct Sensor is fitted.

Allow the heater to run in BYPASS mode and note when the Duct Temperature stops rising, and the time taken to achieve this maximum temperature.

Set P9 to the temperature noted above.

1. Press  or  to select program 9:
SELECT RETURN

9 MAX DUCT TEMP
CURRENT 70

2. Press  to change display to:
PROGRAM















UP/DN TO CHANGE
CURRENT 65

3. Press  or  to set the required temperature.
SELECT RETURN

4. Press  to confirm program changes and return to main menu.
ENTER

P10. Minimum Duct Temperature















Set the Minimum Duct Temperature 8-10 °C below the level set in P9.
If this causes short cycling then set lower, i.e. 10-15 °C.

1. Press  or  to select program 10:
 or 

2. Press  to change display to:


3. Press  or  to set the required temperature.
 or 
4. Press  to confirm program changes and return to main menu.


Note If fitting the duct sensor is impractical, i.e. high level heaters, then use the Cycling Mode programs (P11 and P12) to achieve heater cycling and enhance savings.

P11. On Time (Cycling Mode – no duct sensor fitted)

Set P11 to the time noted to reach Maximum Duct Temperature.

1. Press  or  to select program 11:
 or 

 2. Press  to change display to:


 3. Press  or  to set the required temperature.
 or 
 4. Press  to confirm program changes and return to main menu.

-

12. Off Time (Cycling Mode – no duct sensor fitted)

Set the Off Time to match the P11 On times as shown below:

10 mins ON - 3 mins OFF
 8 mins ON - 3 mins OFF
 7 mins ON - 2 mins OFF
 6 mins ON - 2 mins OFF

These will normally be the most common figures encountered.


1.

Press



SELECT

or



RETURN

to select program 12:

12 SET OFF TIME
CURRENT 10

2.

Press




PROGRAM

to change display to:

UP/DN TO CHANGE
CURRENT 09


3.

Press



SELECT

or



RETURN

to set the required temperature.

4.

Press



ENTER

to confirm program changes and return to main menu.

13. View External Temperature


1.

Press



SELECT

or



RETURN

to select program 13:














13 VIEW EXTN
CURRENT 17.5



The image shows a rectangular LCD display with a black border. The background is a light green grid. The text is displayed in a black, monospaced font. The first line reads "13 VIEW EXTN" and the second line reads "CURRENT 17.5".


This menu option is NOT programmable, but allows you to see the current external temperature when the optional external temperature sensor is fitted.

P14 Calibration

Program 14 allows individual calibration of the Duct, Room (Internal) and External (optional) temperature sensors. Each sensor reading can be adjusted by $-10^{\circ}\text{C}/+20^{\circ}\text{C}$.

1. Press  or  to select program 14
 SELECT RETURN 
2. Press  to change display to: 
 PROGRAM
3. Press  or  to adjust the displayed temp ($-10^{\circ}\text{C}/+20^{\circ}\text{C}$).
 SELECT RETURN
4. Press  to confirm program changes and display: 
 ENTER
5. Press  or  to adjust the displayed temp ($-10^{\circ}\text{C}/+20^{\circ}\text{C}$).
 SELECT RETURN
6. Press  to confirm program changes and display: 
 ENTER

7. Press  or  to adjust the displayed temp (-10°C/+20°C).
SELECT **RETURN**


8. Press  to confirm program changes and return to main menu.
ENTER

Exiting Programming Mode

To exit from the programming mode, first ensure that the display indicates you are in the main menu.

At this point, press  to exit programming mode.
ENTER


The display will change to:



TEC 1750
HEATER CONTROL



And then, after a few seconds to:






FIRING Tu 10:05
DT 70/60 T 45 D

The display may show slightly different information depending on the current mode of operation, i.e. firing, economising etc.

Note: When in programming mode the TEC 1750 will revert to normal running mode if the keypad is not operated for a period of 30 seconds (4 minutes if in program change mode).

To access programming mode from normal running mode:

Press  and then select required program with  .
PROGRAM SELECT RETURN

Make any program changes as described previously.
