

Blueboard Insulation panels – instruction.

Blueboard insulation panels are easily cut with a sharp knife.

Undertile mat systems.

Concrete / Screeded Floors – Ensure floor surface is free of dust and debris prior to bonding boards in place with a good quality **Rapid Set Flexible** Floor tile adhesive, use notched floor tiling comb to apply the adhesive to the floor and bed panels using a straight edge.

NOTE: Do not use solvent based or pre mixed adhesives.

For tiling either directly over Blueboard or to embed electric underfloor heating system use a **Rapid Set Flexible** Floor tile adhesive. Ensure that all heating mats are fully embedded within the tile adhesive.

NOTE: Do not use solvent based or pre mixed adhesives.

A two part latex levelling compound may be applied to embed the heating system prior to tiling if desired.

ThermoLAM under laminate systems.

Blueboard insulation panels are easily cut with a sharp knife.

All sub floor types - Boards to be loose laid in a staggered brickwork fashion, boards can be taped together if required to prevent movement whilst laying out ThermoLAM heating mats.