



## **FUME EXTRACT PLANT - DATASHEET**

02/2012

To operate safely all Fume Cupboards need to be connected to a suitable Fume Extract system. The most common installations are as illustrated below. The correct fan and well-designed duct route are essential to ensure a balanced installation.





Arrangement A

Arrangement B

- · Full site survey carried out prior to installation
- Designed to comply with the latest British Standard
- Centrifugal type Fan
- Rigid PVC Tube and Bends heat welded at joints
- · Discharge terminates in a high velocity outlet
- Support brackets are mild steel suitably painted
- Flexible PVC joint for final connection to fan