


The ABB Guide to

Safety Critical Systems and International Standard IEC 61508





Pre-Design Phases 1 – 5 (End User / Operator) **Setting the SIL Target**



Demand more from your instrumentation.

Demand more from your source.

OR OR