Environme nentation

ency Ultraviolet Gas Production owdered Metals

d Environments

s Manufacturing carbon Refining

Food Packaging s ■ Glove Boxes on Beam ■ R & D Fermentation d Environments Manufacturing ssel Blanketing tion Analysing ncy Ultraviolet Gas Production wdered Metals Environments anufacturing el Blanketing

Production ered Metals

ove Boxes

ufacturing

Analysing

Ultraviolet

Production - J Mota

# 9500/8500 Nitrosave Oxygen Control System stion Analysing

The Nitrosave control system combined with a state of the art trace and percent oxygen measurement technology offers cost of ownership with pay back times in nitrogen savings within a few years.



#### Features & Benefits

- Save on nitrogen usage and rework costs.
- Improve process control and product quality.
- Automatically detects a halt in production and reduces nitrogen flow for even greater savings.
- Extremely fast response time even after high oxygen exursions means quicker process optimisation.

 Nitrosave Viewer PC software makes set up quick and easy.

SYSTECH

- USB and RS485 communications output for data logging can document the whole process.
- Small footprint allows OEM manufacturers to install inside their machines.

**Conforms to European Directives:** 

Electromagnetic Compatibility Directive 89/336/EEC Low Voltage Directive 73/23/EEC

# Save Nitrogen and Improve Process Control

## Nitrosave

nvironments

lanufacturing

sel Blanketing

tion Analysing

ncy Ultraviolet

Gas Production

wdered Metal

Environments

Manufacturing

arbon Refining

ood Packaging

Glove Boxes

n Beam 🔳 R & r

Fermentation

Environments

Manufacturing

sel Blanketing

ion Analysing

cy Ultravioler

ias Productio

dered Metali

nvironments

Inufacturing

Blanketing

Analysing

Ultraviole

Production

red Metal

Ultraviole

Productio

and Mot

Nitrosave consists of the oxygen monitor/control unit and a proportional or other control valve which is fitted into the nitrogen supply line to the machine.

Nitrosave monitors the residual oxygen in the system under control using Systech Illinois' latest cell technology. The oxygen measurement is then used together with a fuzzy logic control algorithm and user-defined setpoints for desired oxygen level, to automatically control the opening of the valve, which regulates the flow of nitrogen into the machine.

This ensures enough nitrogen to comfortably maintain the desired oxygen level is fed into the machine but eliminates the waste seen with fixed-flow nitrogen systems.

Installation of the Nitrosave is very simple and it can be retrofitted to almost all types of machines.

Once in place, setting up the control system is straight forward and can be done when the machine is in production. It is always possible to revert to manual control and the system will automatically select maximum flow in the event of a fault.

Nitrogen is used in soldering and other controlled atmosphere machines to remove oxygen which results in better production quality, however, nitrogen can be expensive.

Systech Illinois' long expertise in the field of Gas Analysis led to the development (in partnership with major soldering machine manufacturers, of the Nitrosave, designed to reduce the nitrogen consumption of your machine.

This technology is easily transferred to other inerted machines. Whether you have a small wave machine or large reflow system, the savings with Nitrosave are considerable. With nitrogen reductions of 25-70%, the payback time for the system is very short, with the added benefits of improvements in process control and full traceability.



#### **Control Valves**

Various sizes, types, flow rates and connections to suit every machine. Allows control of main nitrogen flow or specific zones in the machine.

#### **Outputs & Alarm**

For data logging, chart recorders and remote monitoring

- USB and RS485
- 4-20mA/0-20mA
- 2 high / low alarms
- Fault alarm

#### **Doping Systems**

Mass Flow controlled, or other, doping for control at high oxygen levels (500ppm+). Ideal when soldering BGA components.

#### **Operator Interface**

- User-friendly menu
- Setpoints & alarm settings
- Control configuration
- Read only mode

# Nitrosave Viewer

Datalogging is simple with the provided Nitrosave Viewer program. This allows a log of a number of machine parameters (including oxygen level and valve opening) to be made. The data is stored as a text file which can be easily manipulated and displayed graphically using spreadsheet programs.

## Photoswitch PCB Detector

Automatically detects a halt in production and reduces nitrogen flow for even greater savings.

#### Principle of Operation

Nitrosave uses Systech Illinois' patented RACE sensor\*. A unique electrochemical cell which responds in seconds even to large changes in oxygen levels and is unaffected by solvent vapours or hydrocarbons making it ideal for use in systems where high oxygen events are common.

Development of the RACE<sup>™</sup> cell allows oxygen measurements to be made across the full range normally found in a soldering oven, without delays due to the purging of the measurement system or sample lines. The high speed of the cell ensures a very rapid start up response and accurate monitoring of changes in the machine atmosphere during production.

The RACE™ sensor is maintenance free and requires infrequent only calibration. RACE<sup>™</sup> sensors carry a 3 year limited guarantee.

\* UK Patent no. 2324870 USA Patent no. 5929318



ontact Len inealing 🔳 V amics Comb Oxygen Defi s 🔳 High Puri Alloys and ity 🔳 Control 🔳 Contact Le keting 🔳 Hyd on Analysing ass/Fibre Opt uction 
Elect vdered Metal ity 🔳 Control Contact Ler Annealing 🔳 ramics Comb xygen Defic High Purit Alloys and P Controlled Intact Lens aling 🔳 Ves cs Combust n Deficien and Pow itrolled Ei Lens Ma otics 🔳 G als 🔳 Fe olled En Vesse Deficienc Purity G

# 9500/8500 - Nitrosave Oxygen Control System



Bench/Panel Mount 190H x 237W x 410D (mm) 8.4 kg

**Technical Specifications** 



IP66/NEMA 4X Wall Mount/Weatherproof 460H x 380W x 160D (mm) 15.5kg



Rack Mount 4U - 19 inch Houses 1 or 2 Analysers 178H x 484W x 410D (mm) 9.7kg (single unit)

| Sensor Type<br>Ranges<br>Accuracy<br>Measuring Cell Type<br>Communications<br>Alarms<br>Analogue Outputs | Dependent on Application<br>0.01ppm - 100% O <sub>2</sub> Autoranging<br>Dependent on measurement method<br>Electrochemical or Zirconia solid state, dependent on application.<br>USB and RS485<br>2 programmable changeover contacts, rated 240V 3A<br>1 fault alarm, changeover contact, rated 240V 3A<br>2 scaleable 4-20mA, 0-20mA, all isolated. |
|--|---|
| Operating Conditions<br>Sample Connections<br>Ambient Temperature<br>Sample Gas Flow Rate<br>Power       | 1 for control valve.<br>1/8 inch O/D compression<br>-5 to 50°C (23° to 122°F)<br>100 -300 ml/min (internal pump)<br>230/110 VAC selectable, 80VA  |
| Options<br>Product Sensor<br>Valve Options<br>MFC Doping Option  | Detects halt in production, software can engage new set points.<br>Flow rates dependent on oven. Contact Systech Illinois for more information.<br>Air injection systems.   |

Systech Illinois have over 25 years experience of providing analysis solutions for a wide range of industries. From our manufacturing plants in the UK and U.S we produce gas analysers for industrial process industries, headspace analysers for monitoring gas flushing of food products, and our range of permeation analysers.

Systech Instruments Ltd (UK) 17 Thame Park Business Centre, Wenman Road, Thame, Oxfordshire OX9 3XA Tel: +44 (0)1844 216838 Fax: +44 (0)1844 217220 E-mail: advice@systech.co.uk www.systechillinois.com Illinois Instruments, Inc (U.S) 2401 Hiller Ridge Road Johnsburg, Illinois 60051 U.S.A Tel: +1 815 344 6212 Fax: +1 815 344 6332 E-mail: sales@illinoisinstruments.com

www.systechillinois.com

Illinois Instruments (Thailand) 6th fl Nopnarong Bldg No7 Ladprao23, Jatujak, Bangkok 10900 Thailand Tel: +66 (0)2938 0798 Fax: +66 (0)2938 1058 1 E-mail: mai@illinoisinstruments.com www.systechillinois.com

Systech Illinois reserve the right to change specifications without notice. 09/2010

#### Systech Illinois (China)

Room 519, No.3 FuCheng Building No. 900 Quyang Rd, Hongkou district, Shanghai, China 200434 Tel: +86 21 65533022 Fax: +86 21 65539651 Email: info@systechillinois.cn www.systechillinois.cn

bellowing ontact Lens inealing 🔳 Ve amics Combu Oxygen Defici s 🔳 High Purity Alloys and P lity ■ Controlle 🛯 🔳 Contact Len keting 🔳 Hydro on Analysing ass/Fibre Optic uction 
Electro wdered Metals ity 
Controlle Contact Lens Annealing 🔳 Ve ramics Combus Dxygen Deficie High Purity Alloys and Pov Controlled ontact Lens M aling 🔳 Vesse s Combustic n Deficiency h Purity Gas and Powd ntrolled Env als 🔳 Fern Vessel E ombustion Deficiency Purity Gas