Miniature Electronic Pressure Scanners



ESP-16HD/32HD/64HD

FEATURES

- Unparalleled Long Term Stability
- Advanced Digital Temperature Compensation (DTC)
- Individual Offset and Thermal Zero Compensation
- Automatically Switched Reference Pressures
- Optional Isolated Purge Capability
- Optional Temperature Sense Output

APPLICATIONS

- In-Model Windtunnel Testing
- Aircraft Flight Testing
- Automotive Track Testing



ESP Pressure Scanners are miniature electronic differential pressure measurement units consisting of an array of silicon piezoresistive pressure sensors, one for each pressure port. The sensors are mounted on a common hybrid glass substrate using a proprietary technique which maximizes long term stability. The outputs of the sensors are electronically multiplexed through a single onboard instrumentation amplifier at rates up to 70,000 Hz using binary addressing. The multiplexed amplified analog output is capable of driving long lengths of cable to a remote A/D converter.

The ESP scanners also incorporate a two position calibration manifold actuated by momentary pulses of control pressures. When placed in the calibrate position, all sensors are connected to a common calibration pressure port. A series of accurately measured pressures can be applied through this port to characterize the sensors, in place, at the condition to which they are being subjected. Proper and periodic on-line calibration maintains static errors within +/-0.03% or better of the full scale (FS) pressure range. The calibration manifold automatically switches between two common reference pressures to ensure a stable reference is applied during calibration. The calibration manifold incorporates a visual position indicator and utilizes a dynamic o-ring seal design for high reliability and easy servicing in the field.

Options include purge capability, isolated from the pressure sensors, to clear measurement lines of moisture and contamination as well as to prevent closure of model pressure taps during application of pressure sensitive paint. Other options include a nickel foil RTD output to monitor internal scanner temperature and Digital Temperature Compensation technology now incorporating PSI's Gen-2 amplifier technology.

The Digital Temperature Compensation (DTC) option incorporates the latest PSI innovations in ESP technology including temperature signal outputs from each silicon pressure sensor, embedded EEPROM retaining factory calibration information including temperature characteristics, programmable dual gain amplifier with optional dual range calibration, calibration manifold position sensing, and internal sensor excitation regulation with sense output. DTC Series ESP scanners are supported by PSI's DTC Initium System and the SDI configuration of the System 8400 to dramatically reduce calibration requirements. The ESP scanners are also supported by a variety of third party compatible systems.

34 Research Drive Hampton, VA 23666 USA www.PressureSystems.com

 Phone:
 757-865-1243

 Toll Free:
 800-328-3665

 Fax:
 757-865-8744

 E-mail:
 sales@PressureSystems.com

ISO-9001:2000 Certified

© Copyright Pressure Systems, Inc., 2009

Specifications

Specifications subject to change without notice. After 1 hour warmup @ 25°C with atmospheric reference pressure unless otherwise stated

	DTC		e pressure unless otherwise stated. CONVENTIONAL			Unite	Commente							
Parameter	32HD	64HD	16HD 32HD 64HD		Units	Comments								
PNEUMATICS														
Number of Pressure Inputs	32	64	16	32	64	ports								
Pressure Range ¹), ±2.5 (17), :	±10 (2.5), ±20 (5.0) =5 (34), ±10 (69) , ±15 (103), 310), ±50 (345), +100 (689)			in WC (kPa) psid (kPa) psid (kPa)								
Proof Pressure ²			400 150		% FS % FS	range ≤ 30 psid range > 30 psid								
Max Reference Pressure (Line Pressure)			50 (345) 15 (103)		psid (kPa) psid (kPa)	range								
Manifold Control Pressure			100 (689) 125 (862)		psig (kPa) psig (kPa)	min max								
Optional Purge Pressure			an max inpu 150 (1050)			psig (kPa) psig (kPa)	min max							
Media: Measurement Ports	non-corros	non-corrosive gases up to 100% non-condensing humidity												
Reference Ports		dry, no	n-corrosive	gases										
Pneumatic Connection	0.040 or 0.063	0.040	0.040 or 0.040 or 0.040 or 0.063 0.063		inches OD	SS bulged tubulation								
PERFORMANCE	I													
Static Accuracy ³ @100% range ⁴				% FS % FS % FS	range ≥ 5 psid range ≥ 10 in WC to < 5 psid range < 10 in WC									
@33% range ⁷	±0	.05		N/A		% FS	range ≥ 5 psid							
2 nd order correction ⁵		/A /A	±0.15 ±0.20			% FS % FS	range > 2.5 psid range ≤ 2.5 psid							
4 th order correction ⁶		/A /A	±0.05 ±0.10			% FS % FS	range > 2.5 psid range ≤ 2.5 psid							
Thermal Zero Error	N	N/A ±0.06 ±0.20			% FS/ºC % FS/ºC	range > 2.5 psid range ≤ 2.5 psid								
Thermal Span Error	N	/A	±0.02 ±0.03			% FS/°C % FS/°C	range > 2.5 psid range ≤ 2.5 psid							
Total Thermal Stability @100% range	±0.	002 004 01	N/A N/A N/A		N/A		N/A		N/A		N/A		% FS/°C % FS/°C %FS/°C	range ≥ 5 psid range ≥ 10 in WC to < 5 psid range < 10 in WC
@33% range ⁷	±0.	003	N/A			% FS/°C	range ≥ 5 psid							
Line Pressure Effect			±0.001 ±0.002			% FS/psi % FS/psi	range > 2.5 psid range ≤ 2.5 psid							

NOTES:

Consult factory for pressure ranges not listed 1

2 Maximum applied pressure without reducing sensor performance

3 Static accuracy includes combined errors due to non-linearity, hysteresis, and non-repeatability

4 Achievable static accuracy after span calibration. Consult applicable datasheets for DTC Series ESP specifications when used with PSI's System 8400 SDI configuration or DTC Initium system.

5

Typical performance using 2nd order equation of the form $P_x = C_0 + C_1 (V_x) + C_2 (V_x)^2$ Typical performance using 4th order equation of the form $P_x = C_0 + C_1 (V_x) + C_2 (V_x)^2 + C_3 (V_x)^3 + C_4 (V_x)^4$ 6

7 Accuracy is expressed as a percent of the deranged Full Scale when dual range calibration is specified. Applicable when Dual Range Calibration is specified.

Specifications

Specifications subject to change without notice.


Domenter	DTC		CONVENTIONAL			Unite	Commente			
Parameter	32HD	64HD	16HD	32HD	64HD	Units	Comments			
ELECTRICAL										
Power Supply +5 VDC +12 VDC -12 VDC	0 75 25	0 110 25	25 5 3	55 5 3	75 5 3	mA mA mA	max max max			
Full Scale Output	±3.5 – 4.5					VDC	optional output available			
Port Selection	5	6	4	5	6	bit	0-12 VDC, CMOS Logic			
Scan Rate	70,0	000	20,000							
Electrical Connection		15 pin su	ıbminiature	D-shell ⁸			ITT Cannon (PN: MDM 15SSB)			
Environmental/Physical										
Comp Temp Range			0 to 80			°C				
Operating Temp Range			-25 to 80		°C					
Storage Temp			-25 to 100		°C					
Weight	3.9 (112)	5.1 (143)	1.63.74.9(46)(106)(140)		oz. (g)					
HEATER CHAMBERS										
Setpoint Adjustability			±3		°C					
Thermal Compensation	N//	A ⁹		10:1			reduction in the effects of temperature to the scanner			
Ambient Temperature			-55		°C	min				
Power Requirements		28	3 VDC @ 1.	5A		max				
Electrical Connection		Two le	eads untern	ninated		Red: +28 VDC Black: GND				
Temperature Overload			90			°C	with Auto Reset			
Weight	6.8 (192)	6.8 (192)	5.66.86.8(157)(192)(192)			oz. (g)				

NOTES:

ESP-16HD supplied with intermediate cable terminating with 15-pin subminiature D-shell 8

PIN

9 Heater chambers for DTC Series scanners are only required to maintain minimum operating temperature.



- FUNCTION
- FUNCT Digital Address A0 Digital Address A1 Digital Address A2 Digital Address A3 Digital Address A4 1 2
- 3
- 4
- 5 6 7 +12 VDC -12 VDC
- 8 +VS, Sensor Supply Voltage (+5)


- FUNCTION
- -VS, Sensor Suply Voltage Return
- 10 GND 11

PIN

9

- Voltage Output V₀
- 12 Digital Address A5
- GND Sense 13 14
- +VS Sense (opt.) 15
 - Vt, Temperature Sense Output (opt.)


Interfacing to the ESP-HD Series scanners consist of both electrical and pneumatic considerations. The DTC Initium, System 8400 and S8256 Flight System provide turnkey pre-engineered solutions to these interfacing requirements. Custom data acquisition systems will require these interfaces to be developed.



¹ S1 · FOR REZERO ONLY.

② S2 · TO SHUTTLE MANIFOLD.

③ * ONLY REQUIRED FOR SCANNERS ORDERED WITH PURGE OPTION.




Options

ESP

Digital Temperature Compensation (DTC)

The DTC option of the ESP pressure scanners incorporates many advanced features including the Gen-2 amplifier technology to increase the utility of the scanners while providing digital temperature compensation of the silicon sensors.

An onboard EEPROM stores the thermal calibration data for each channel. Also stored in the EEPROM is information identifying the range of the scanner, the number of channels, the model number, the serial number, the date of manufacturer, the date of calibration, and the model and serial number of the calibration unit used to calibrate the scanner. This data is serially transmitted to a data acquisition system such as the DTC Initium or to the Scanner Digitizer Interface (SDI) of the System 8400 using the ESP



address lines and then transferred to the 8400 System Processor via fiber optic cable.

Using a proprietary PSI-developed method, the temperature of each sensor within the scanner is measured and transmitted along with the raw pressure measurements to the data acquisition system. Utilizing the calibration data within the EEPROM, the data acquisition system compensates for temperature changes to the sensors in real time. This reduces thermal errors by a factor of 20 thereby reducing on-line calibration requirements by up to 90%.

The ESP scanners also incorporate a hall effect sensor which is used to indicate the position of the calibration manifold. This position information can be transferred to the system upon command.

Another advanced feature is the ability to derange the ESP scanner upon command. This alters the gain on the amplifier to derange the scanner by a factor of three, enabling additional windtunnel tests to be conducted without reinstrumenting the model with lower range ESP scanners. To optimize the accuarcy of the DTC scanner at the highest gain, the optional dual range calibration is recommended.

Temperature Sense Output Option for Conventional ESP Scanners

The temperature sense output option involves embedding a nickel foil RTD within the scanner to indicate internal scanner temperature. The analog signal from the RTD is output on one of the pins of the electrical connector.

Silicon sensors are repeatable with temperature and, once characterized, can be compensated for thermal errors using algorithmic techniques. Scanners with this option are factory calibrated at temperature intervals throughout the operational temperature span of the scanner and a curve fit established for each sensor.

A fourth order polynomial equation is generated for each sensor at standard temperature points of -25, 0, 25, 50 and 75°C. These equations as well as the corresponding RTD voltages are provided to customers in a calibration report along with the scanner.

The temperature sense option can be ordered with the scanner or existing scanners can be retrofitted by returning the scanner to the factory for upgrade. (See page 12 for order information.)


Pneumatic Connections

Pneumatic connections to the ESP scanners are made via user-specified 0.040" or 0.063" OD bulged stainless steel tubulations installed on the scanner tubing plate. Tubulations of 0.040" OD can optionally be installed at a 60° angle to minimize the overall height of the scanner. Scanners specified with Purge option must be installed at the standard 90° angle unless the Quick-Disconnect option is also specified.

Flexible tubing is installed over the bulged tubulation and secured using retaining springs. Pressure Systems offers nylon tubing, retaining springs and tubing pliers to facilitate the installation of the tubing and springs. (See page 12 for ordering information).

Purge Option

The purge option involves a modification to the scanner's calibration valve to manifold purge pressure inputs to the measurement ports during calibration. Anytime the valve is placed in the calibrate position, purge pressure applied to the purge ports will purge the measurement lines of any contamination such as moisture. This option enables simultaneous purging and calibration (or rezero) which is especially useful in flight test applications. The purge option is also useful for preventing model surface pressure taps from becoming clogged during the application of pressure sensitive paint. During use, purge pressure **must** be present whenever the valve is shifted to the calibrate position to prevent "reverse" purge from occurring.



Heater Chambers


Heater chambers are available to insulate the ESP miniature pressure scanners from temperature changes and reduce the thermal effects by a factor of ten. The heater chambers are constructed of Delrin, a lightweight material with good insulation qualities. The scanners are housed within an embedded copper liner to evenly distribute the heat generated by the foil heating element. The heater circuitry includes proportional temperature control, adjustable temperature setpoint, and thermal overload protection. The +28 VDC power supply is input via two unterminated leads. The ESP scanners are mounted to the heater chamber top plate which includes an opening to route measurement lines to the scanner. A rubber grommet is provided to allow the scanner electrical cable to enter the heater chamber while thermally sealing the opening. The heater chambers also incorporate mounting provisions. (See page 3 for heater chamber specifications, page 8-11 for dimensions and page 12 for order information.)

Quick Disconnect ESP Tubing Plates

Quick-Disconnect ESP tubing plates enable users to disconnect the tubing plate from ESP-32HD or ESP-64HD scanners without exposing the internal calibration manifold to potential contaminants. Separating the tubing plate from the scanner helps reduce setup times by allowing tubing connections to be completed while simultaneously conducting electrical checkout of the scanner. The Quick-Disconnect option enables angled tubulation to be specified in conjunction with the Purge option.

Quick-Disconnect tubing plates can be ordered as an option on new ESP scanners or as a retrofit kit for

field installation. Each kit comes with installation instructions and is comprised of four (4) components: tubing plate, receiver plate, and two protective cover plates. Individual components may also be ordered as replacements.



Maintenance Kits and Spare Tubing Plates

To supplement the on-site ability to replace the transducer carriers and the amplifier assembly, maintenance kits are offered to service the calibration valve and tubing plate. These kits are available for each of the scanner models.

The maintenance kits consist of spare bulged tubulations, a drill bit to clean the tubulation bore in the tubing plate, and the sealant to secure the tubulation to the plate. Also included are spare "O" rings for the calibration manifold and the pistons along with a generous supply of lubricant. Additional "O" rings can be purchased separately. Spare tubing plate screws are also provided.


Spare tubing plates can be used to replace damaged tubing plates or to alter the pneumatic connections of the scanner. When ordering spare tubing plates, the manifold configuration (standard or purge) as well as the ESP model must be indicated along with the pneumatic connection.

Instructions for servicing the ESP scanners using these maintenance kits are provided in the ESP Miniature Scanners User's Manual. (See page 12 of this datasheet for order information.)

Cables


Pressure Systems offers a variety of cables including a mating connector with wiring harness to facilitate electrical connection to the system. These cables are custom designed to maximize noise immunity and flexibility. These cables can be used to interface the ESP miniature scanners to the DTC Initium, System 8400, and S8256 Flight System Scanner Interfaces or to custom data acquisition systems. Both PVC and PTFE jacketed cables are available.

ESP-16HD



Spec Diagrams


ESP-32HD



	ESP-32HD	a (length)		b (width)		c (height w/o tubes)		d (height incl. tubes)	
		in	mm	in	mm	in	mm	in	mm
	0.040" OD, straight	2.80	71.1	1.00	25.4	0.93	23.7	1.17	29.8
	0.040" OD, angled	2.80	71.1	1.00	25.4	0.93	23.7	1.17	29.6
	0.063" OD, straight	2.80	71.1	1.00	25.4	0.93	23.7	1.18	30.0
ဂ္ဂ	0.040" OD, straight, purge	2.80	71.1	1.00	25.4	0.93	23.7	1.36	34.5
onv	0.063"OD, straight, purge	2.80	71.1	1.00	25.4	0.93	23.7	1.36	34.5
ent	0.040" OD, straight, QDC	2.80	71.1	1.00	25.4	1.12	28.4	1.36	34.6
Conventional	0.040" OD, angled, QDC	2.80	71.1	1.00	25.4	1.12	28.4	1.35	34.3
a	0.063" OD, straight, QDC	2.80	71.1	1.00	25.4	1.12	28.4	1.37	34.7
	0.040" OD, straight, QDC, purge	2.80	71.1	1.00	25.4	1.12	28.4	1.54	39.2
	0.040" OD, angled, QDC, purge	2.80	71.1	1.00	25.4	1.12	28.4	1.53	39.0
	0.063" OD, straight, QDC, purge	2.80	71.1	1.00	25.4	1.12	28.4	1.54	39.2
	0.040" OD, straight	3.10	78.7	1.00	25.4	0.93	23.7	1.17	29.8
	0.040" OD, angled	3.10	78.7	1.00	25.4	0.93	23.7	1.17	29.6
	0.063" OD, straight	3.10	78.7	1.00	25.4	0.93	23.7	1.18	30.0
D	0.040" OD, straight, purge	3.10	78.7	1.00	25.4	0.93	23.7	1.36	34.5
DTC	0.063"OD, straight, purge	3.10	78.7	1.00	25.4	0.93	23.7	1.36	34.5
Series	0.040" OD, straight, QDC	3.10	78.7	1.00	25.4	1.12	28.4	1.36	34.6
ries	0.040" OD, angled, QDC	3.10	78.7	1.00	25.4	1.12	28.4	1.35	34.3
	0.063" OD, straight, QDC	3.10	78.7	1.00	25.4	1.12	28.4	1.37	34.7
	0.040" OD, straight, QDC, purge	3.10	78.7	1.00	25.4	1.12	28.4	1.54	39.2
	0.040" OD, angled, QDC, purge	3.10	78.7	1.00	25.4	1.12	28.4	1.53	39.0
	0.063" OD, straight, QDC, purge	3.10	78.7	1.00	25.4	1.12	28.4	1.54	39.2

Conventional Spec Diagrams

ESP-64HD




	ESP-64HD	a (length)		b (width)		c (height w/o tubes)		d (height incl. tubes)	
		in	mm	in	mm	in	mm	in	mm
	0.040" OD, straight	2.80	71.1	1.30	33.0	1.00	25.4	1.23	31.3
C	0.040" OD, angled	2.80	71.1	1.30	33.0	1.00	25.4	1.19	30.1
vnc	0.040" OD, straight, purge	2.80	71.1	1.30	33.0	1.13	28.6	1.55	39.4
ent	0.040" OD, straight, QDC	2.80	71.1	1.30	33.0	1.31	33.3	1.55	39.2
ion	One 0.040" OD, angled 0.040" OD, straight, purge 0.040" OD, straight, QDC 0.040" OD, angled, QDC 0.040" OD, straight, QDC, purge		71.1	1.30	33.0	1.31	33.3	1.50	38.1
al			71.1	1.30	33.0	1.31	33.3	1.74	44.1
	0.040" OD, angled, QDC, purge	2.80	71.1	1.30	33.0	1.31	33.3	1.55	39.5
	0.040" OD, straight		80.0	1.30	33.0	1.00	25.4	1.23	31.3
	0.040" OD, angled	3.15	80.0	1.30	33.0	1.00	25.4	1.19	30.1
TC	0.040" OD, straight, purge		80.0	1.30	33.0	1.13	28.6	1.55	39.4
	0.040" OD, straight, QDC	3.15	80.0	1.30	33.0	1.31	33.3	1.55	39.2
Series	0.040" OD, angled, QDC	3.15	80.0	1.30	33.0	1.31	33.3	1.50	38.1
0	0.040" OD, straight, QDC, purge	3.15	80.0	1.30	33.0	1.31	33.3	1.74	44.1
	0.040" OD, angled, QDC, purge		80.0	1.30	33.0	1.31	33.3	1.55	39.5

Conventional Heater Chambers


#8-32 UNC x .50 dp.[12.7mm] (4 places)

ESP-16HD



ESP-64HD

ESP-32HD




4.200 [106.68mm]


ESP

DTC Series Heater Chamber

ESP-32HD



ESP-64HD



Ordering Information

Pressure Scanne	er:						
PN: 16HD-AABB PN: 32HD-AABB PN: 64HD-AABB	CCDDFF	ESP-16HD Scanne ESP-32HD Scanne ESP-64HD Scanne	er, 32 channels				
AA =	Pressure Range ((19, ±4"WC (1.0 kPa 01, ±10"WC (2.5 kF 02, ±20"WC (5.0 kF 03, ±1 psid (7 kPa)	Pa) 05, ±5 p Pa) 06, ±10	pressure ranges no 5 psid (17 kPa) psid (34 kPa) psid (69 kPa) psid (103 kPa)	30 90	3, ±30 psid (207 kPa) 9, ±45 psid (310 kPa) 0, +100 psid (689 kPa)		
BB =	03, 0.063", 90° (16 11, 0.040", 90°, qu 12, 0.040", 60°, qu	ot available with Purge)/64HD only) /64HD only)	CC = EE =	Manifold Options 00, Standard 02, Purge option Intermediate Cable Length (16HD only) 01, 1 foot 02, 2 feet		
DD =	 Digital Tempera range calilbration Digital Tempera 	ense with PROM	, 0	FF =	03, 3 feet 04, 4 feet 05, 5 feet 06, 6 feet For requirements in excess of 6 feet, use ESCB scanner extension cable Amplifier Generation 32HD & 64HD only) 00, Conventional 20, Gen-2 DTC (DD must = 11 or 12)		
Spare Quick-Dise 32QD-AABBCC00 64QD-AABBCC00	000	Quick-Disconnect Quick-Disconnect					
AA =	Kit Configuration 00, Complete 4-pie 01, Receiver plate 02, Tubing plate or 03, Protective plate	only nly					
BB =	BB = Pneumatic Configuration (OD, angle) 00, N/A 11, 0.040", 90° (32HD/64HD only) 12, 0.040", 60° (32HD/64HD only)				Manifold Options 00, Standard 02, Purge		
	13, 0.063", 90° (3:	2QD only)	Notes: 32QD with purge option uses 0.125" OD purge tubes on all pneumatic configurations 64QD with purge option uses 0.090" OD purge tubes on 90° pneumatic configurations and 0.063" OD purge tubes on 60° pneumatic configurations				
Heater Chamber:			Not available with he	eater chamb	er option		
PN: 16HC-AA000 PN: 32HC-AA000 PN: 64HC-AA000	00000	ESP-16HD Heater ESP-32HD Heater ESP-64HD Heater	Chamber				
AA =	Type of Scanner 01, Conventional 02, DTC						
Order Example:	32HD-0103021		D Scanner, ±10"We tion with single rar		90°, purge, digital temperature ation		