



# What do we mean by Types A, B & C Waterproofing?



Waterproofing is the process of making an object or structure waterproof or water-resistant so that it remains relatively unaffected by water or resisting the ingress of water under specified conditions. Buildings all around the world rely on structural waterproofing systems.

#### THE DIFFERENCE BETWEEN WATERPROOF AND DAMP PROOF?

Waterproof refers to the penetration of water (in its liquid state) and possibly under pressure. Structural waterproofing is a general term within the industry that covers methods and treatments to describe waterproofing any structure. Waterproofing or Structural Waterproofing is applicable to any construction under-ground or below ground level.

Damp proof refers to resistance to humidity or dampness. Damp proofing is a general term that covers methods and treatments used to prevent damp from being absorbed through walls or floors into the interior of a structure above ground.

# BS8102:2009

BS8102:2009 Code of Practice for the Protection of Below Ground Structures Against Water from the Ground is the British Standard which gives recommendations and provides guidance on methods of dealing with and preventing the entry of water from surrounding ground into a structure at below ground level. It states that there are 3 types of waterproofing protection:

# TYPE A (BARRIER) PROTECTION

Type A (Barrier) Protection, also historically referred to as











"Tanking", provides protection against ground water ingress by applying a waterproof material to the internal or external walls and floor slab of a basement or underground structure forming a barrier between the structure and any groundwater present.

Historically, methods for Type A systems included internal, external and sandwich.

## TYPE B (STRUCTURALLY INTEGRAL) PROTECTION

Type B protection is provided by the structure itself against water ingress. Type B Protection relies heavily on the design and materials incorporated into the external shell of the structure.

Design, materials, as well as the quality of the workmanship contribute to the success of Type B Systems. The pattern of any seepage encountered is often associated with poor joints, cracks or other discontinuities such as service penetrations.

## TYPE C (DRAINED) PROTECTION

Type C protection is provided by the incorporation of an appropriate internal water management system.

Type C Protection allows moisture or running water to penetrate through the external wall or floor of the structure and to travel behind the membrane in a controlled drainage system. Type C systems collect and manage any water ingress by diverting it into a designated safe point of disposal (such as a sump pump/package pump station).

Cavity Drain Membranes are studded on the external facing surface, allowing any water that penetrates the structure to flow into designed drainage channels. The drainage channels carry any water ingress to either a sump and pump chamber or away from the structure if passive drainage is possible.



Head Office: Delta House, Merlin Way, North Weald, Epping, Essex, CM16 6HR