

Humidity and Dew-Point Calibration

Instruments, Systems & Services





Michell Instruments has 40 years' experience providing moisture measurement & calibration solutions to our customers

Contents

A Background to Calibration	5
Choosing the Correct Moisture Calibration Syst	e m 9
Calibration System Selection Guide	15
Pressure Swing Dryers	18
Dew-Point Generators	20
DG3	20
DG2	21
DG4	22
VDS3	23
How Does Chilled Mirror Technology Work?	24
Chilled Mirror Product Comparison Table	25
Optidew Vision	26
S8000 Chilled Mirror Series Features	28
S8000 Integrale	30
S8000 Remote	32
\$8000 RS	34
S4000 Series	36
Integrated Calibration Systems (Dew Point)	38
HG1	38
DCS - Dew-Point Calibration Systems	40
Integrated Calibration Systems (RH)	42
HygroCal100	42
S904	44
OptiCal	46
HG10	48
Abbreviations	68
Glossary	69

Michell Instruments

Global leader for trace moisture, humidity and oxygen analysis

Michell Instruments is an international leader in high-precision sensing, with 40 years experience in the field, specializing in instrumentation for dew point, relative humidity and oxygen analysis.


Michell Instruments has a long history in the field of humidity calibration, originating in the design and provision of the Transfer Standard Dew-point Hygrometer (TSDH) to provide traceability to NIST (National Institute of Standards and Technology) for European calibration laboratories. As the largest manufacturer of dew-point sensors in Europe, Michell Instruments has over 2000 sensors under calibration at any moment in time, in our own production facility in Ely, UK, in addition to local calibration centres in situated in the Netherlands, France, Italy, Germany, China, Japan and USA. The development and optimization of our own calibration systems has helped us to build a comprehensive portfolio of calibration products and solutions that enable our customers to perform their own on-site humidity calibrations.

Manufacturing, Research and Development

Michell Instruments has three manufacturing and R&D locations: Oosterhout, The Netherlands; Lyon, France and Ely UK. The UK location is the main BS EN ISO 9001:2008 certified manufacturing facility.

Service and Support

Michell Instruments offers practical and flexible after-sales service: Whether you prefer on-site maintenance, return to base or service exchange; we provide the simplest way to maintain your measurement. Michell Instruments operates extensive network of subsidiaries and distributors stretching across 56 countries, offering the services of trained application engineers. Service centres and calibration laboratories are located on three continents: North America, Europe and Asia.



Accreditations

Michell Instruments understands and endorses the need to conform to recognized standards for quality and calibration. Our calibration laboratory maintains full traceability to British (NPL) and American (NIST) Humidity Standards.

UKAS

Michell Instruments Limited has been accredited to ISO 17025 by UKAS (United Kingdom Accreditation Service) for the calibration of dew-point hygrometers since 1986 (laboratory number 0179) and our current dew-point calibration range is -90 to +90°C (-130 to +194°F). For full details of our measurement capability please see our Schedule of Accreditation. Our traceability to NIST (National Institute of Standards & Technology) is over the range -75 to +20°C (-103 to +68°F).

NVLAP

Our UKAS accreditation is commonly recognised elsewhere in the world as EAL, or NVLAP (National Voluntary Laboratory Accreditation Program) in the USA.

ISO 9001

Michell Instruments Ltd UK manufacturing facility has been continuously registered to BS EN ISO9001 since 1989.

Hazardous Area Products

Michell Instruments also produces instruments specifically designed for use within hazardous areas. All such products are independently assessed and certified to many international standards, including, but not limited to, ATEX (European), IECEx, CSA, FM, UL, GOST-R and GOST-K. Accreditations and certificates for these products can be downloaded from the www.michell.com under the Product Documents/Accreditations section.







A Background to Calibration

The following guide will provide you with some essential knowledge about humidity calibration, helping you to better understand your own requirements when selecting an appropriate solution from our comprehensive range of humidity calibration equipment.

Why is Calibration Important?

Reputable manufacturers will provide calibration certificates with instruments or sensors at the time of purchase. However, this is not a guarantee of the measurement performance throughout the entire lifetime of the equipment. Over time, the ageing of mechanical and electronic components can cause changes in the characteristics of sensors or instruments. More critically, once the device has been used in the field, and possibly introduced to contaminants which can have an impact on accuracy, it is difficult to say with any degree of certainty whether or not the original calibration is still valid.

When the readings provided by a sensor or instrument are critical to a process or testing procedure, it is vital to know that the device is still performing within its original specifications, or if new correction factors need to be applied.

When an instrument is re-calibrated, a report is provided showing the calibration corrections before, and after, any adjustment was performed. For many hygrometer users, these 'readings before' are crucial, as they can be retrospectively applied to readings taken in the period before calibration.

In order to minimize uncertainty and have confidence in measurements made with the instrument, it is important to have the quality assurance of a regular, accredited calibration procedure.

What is Calibration?

Calibration is the process of comparing a measuring instrument against an authoritative reference to identify any bias or systematic error in the readings. The reference instrument in any calibration should ideally be at least 10 times as accurate as the instrument under test to avoid the tolerances of the reference influencing whether the test instrument is classed as a 'pass' or 'fail'. Generally, a calibration will be performed by repeating the process of comparison at a representative selection of points across the measurement range.

Calibration is often interpreted as 'adjustment of an instrument to read correctly', but this is a misconception. Adjustment of an instrument to match a calibrated reference is a separate concept. It is a process which is usually carried out by the equipment manufacturer, by internally applying the calibration corrections to bring the output readings into line with the indications of the calibration reference. At the end of the calibration, a certificate is issued.

Calibration Standards and Traceability

The best way to ensure accuracy of measurement is through traceability to attested standards. This leads to consistency of measurements across different instrumentation, locations and users. Traceability is an unbroken chain of calibrations which relate a working hygrometer back to a national standard.

Most countries hold their own authoritative national standard for dew point and humidity, which forms the primary measurement standard. Alternatively, reference standards are shared across a region. The reference instruments of calibration facilities in the country or region are calibrated against this primary standard, and are then used as references or 'transfer standards' to calibrate other instruments. This approach can be represented by the pyramid graphic (*Fig. 1*).




Fig. 1 - Calibration Standards and Traceability Pyramid

Humidity Calibration Theory

Humidity calibrations involve generating a stable level of humidity in a sample gas, measuring this with a suitable fundamental reference instrument and the instrument under calibration, and making a comparison of the readings.

A humidity calibration system comprises of:

- A dry air source
- A humidity generator to provide the desired moisture content
- A reference instrument which is more accurate than the instrument under test to provide an authoritative measurement
- A manifold to supply calibration gas to the sensors/instruments under test

If the calibration is being performed in terms of relative humidity and temperature, then the manifold must be temperature controlled or placed in a temperature-controlled environment in order to determine the relative humidity by associating the generated dew-point value with the temperature.

Michell Instruments is the only supplier to offer complete dew-point calibration systems and individual calibration components, all of which are designed and built in-house.



Typical Calibration Certificate

Information that should be included on the calibration certificate:

CERTIFICATE OF CALIBRATION Certificate Number 0000 • Date of Issue 04 th January 2012 • OT9 OT9	——— A unique reference number identifying the certificate or calibration run
48 Lancaster Way Business Park Tel: +44 (0)1353 65600 Ely: Cambre Bark United Kingdom Page 1 of 2	Calibration location
Customer Sample Customer Customer address Sample Address Customer order number Sample Order Number Received O7 th December 2011 Instrument Michell Dewpoint meter	Customer details, sometimes including the customers address, customer number or order number
Model Optidew Vision Serial number Instrument 123456 Sensor 123456.	Any serial numbers that identify the instrument, and associated measuring components
Michell reference number T12345 Measurements performed 10 th to 22 rd December 2011 Laboratory temperature 21 ±2 °C Laboratory humidity 35 ±10 %rh	The date of the calibration, and sometimes the date when the subsequent calibration is due
The hygrometer was calibrated by comparison using reference instruments with UKAS calibration certificates. The Dewpoint sensor was placed in a sensor block through which the sample air passed. The sample air was divided to give one path through the reference hygrometer and the other through the test hygrometer. At 21 °C, the sensor temperature was controlled, by placing the sensor in a liquid cooled sample block, and circulating fluid through it. The fluid temperature is controlled by a re-circulating bath to within ±1.0 °C of the nominal value and ±0.5 °C stability. At the higher temperatures the calibration was performed in a climatic chamber to within ±0.3 °C of the nominal value. The temperature probe was placed approximately 10 mm from the two reference probes. The calibration was performed in a climatic chamber. The optical surfaces of the hygrometers were cleaned using de-ionised water, prior to the calibration. The output used from the hygrometer was the digital display with a resolution to 0.1 °C.	A list of calibrated equipment used during the calibration, or a list of unique identifiers corresponding to that equipment (not shown on this example certificate)
This certificant is issued in accordance with the backness people accordination requirements of the Usined Kingstow Accordination periods. It provides security of meansumment to recognized underest analysis, and in units of meansummer instituted the National Physical Education of other recognized analysis and standards lateratories. This certificate may not be reproduced other than in full, except with the prior written approval of the issuing lateratory.	CERTIFICATE OF CALIBRATION UKAS Accordited Calibration Laboratory 0179
calibration certificate will contain a ble with a list of calibration points:	Certificate Number 00000 Page 2 of 2 At each Dewpoint, time was allowed to ensure that the calibration conditions had stabilised. This was confirmed while recording the 10 readings (at 2 minute intervals) that are averaged to give the figures recorded in this certificate. No adjustment was made to the hygrometer before the calibration was performed.
e 1st column shows the measured value indicated by the	The measured sample flow rate through the Dewpoint sensor was 1.0 l/m. Generated

The 1st column shows the measured value indicated by the reference instrument

The 2nd column shows the measured value indicated by the instrument under calibration

The 4th column shows the correction that should be applied to any measured values obtained from the instrument under calibration

The correction is derived from the difference between the measured value indicated by the reference instrument and that indicated by the instrument under calibration.

Generally, if the instrument under calibration has multiple ways to report the measured value, (i.e. built-in display, digital output, analog voltage or current outputs), then the values taken from these different outputs will also be shown on the certificate at each calibration point.

An estimation of uncertainty over the range of the calibration

Dewpoint Sensor Temperatu °C Dewpoin Correctio °C wpoir Expar Uncert ainty °C 21 -0.2 ±0.21 -5.03 -4.9 21 -0.1 ±0.19 10 3 21 +0.1 ±0.18 25.06 25.1 45 0.0 ±0.25 39.9 45 +0.1 39.98 ±0.25 70.10 70.1 75 0.0 ±0.25

Applied Temperature	Test hygrometer			
°C	Temperature °C	Temperature Correction °C	Expanded Uncertainty °C	
10.03	10.0	0.0	±0.19	
25.05	25.0	+0.1	±0.19	
40.07	40.0	+0.1	±0.19	
70.01	70.0	0.0	±0.18	

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a level of confidence of approximately 95 %. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

The uncertainties quoted in the Certificate of Calibration only apply to the measured value obtained during the period of calibration and are not indicative of the long-term stability of the instrument under test.





In-House Calibration vs. External Calibration

Meteorological organizations, standards laboratories, pharmaceutical manufacturing plants, and other businesses or institutions that operate many calibrated instruments or sensors must have an effective calibration system in place. It is usually more sensible to perform calibrations in-house, rather than managing the cost and downtime (or availability of replacement calibrated sensors) associated with sending equipment away to an external commercial calibration laboratory.

However, purchasing and operating a dedicated humidity calibration system can be a significant commitment in terms of initial cost, personnel training, record keeping, and in some cases physical space. For companies that use a small number of humidity instruments, sending these to a commercial calibration laboratory for regular calibration is the most cost-effective solution.

Michell Instruments Calibration Services

Michell Instruments offers a calibration service for most moisture sensors and instrumentation, carried out against test equipment traceable to national standards at NPL (National Physical Laboratory, London, UK) and NIST (National Institute of Standards & Technology, Maryland, USA) through Michell's ISO/IEC 17025 UKAS (United Kingdom Accreditation Service) accreditation.

We provide traceable calibration from -100 to +90°C (-148 to +194°F) dew point, or full ISO 17025 accredited calibrations from -90 to +90°C (-130 to +194°F) dew point.

Michell Instruments Service Exchange Scheme

In some cases it is not practical for a user to remove a working sensor in order to return it to our lab for recalibration. For this reason Michell Instruments offers an exchange program for sensors, to help customers keep their processes running cost effectively with virtually no down-time.

Before re-calibration is due, the customer orders an exchange sensor from Michell Instruments or one of our global representatives. Once received at the customer's premises, the original sensor is removed and replaced with the exchange sensor, and the original is returned to Michell Instruments. All calibration data is stored within the sensor, so no additional work is required. Each sensor comes with a traceable calibration certificate as standard.

The returned sensor is refurbished and fitted with a replacement sensor tile, and is then used for future service exchange replacements. This means that the service can be offered for the same price as a return-to-base re-calibration.

Michell Instruments also offer a range of extended maintenance policies, which cover annual servicing, recalibration & software upgrades for a wide range of instruments. Please contact your Michell Instruments representative for pricing details on policies providing cover for up to 4 years.




Choosing the Correct Moisture Calibration System

Measurement Parameter

The process of deciding which calibration system is best suited to your needs is dependent on the devices to be calibrated and their measurement parameters.

Dew Point

If the devices are measuring dew point, then the calibration manifold is usually situated in an ambient temperature environment. As dew-point calibration systems are frequently intended to produce very low moisture contents, the manifold needs to be of a high integrity design; working with the sealing mechanism of the sensor to ensure that moisture ingress from the ambient environment is prevented. For extremely low dew points (<-80°C (<-112°F)) it is sometimes necessary, (depending on the ambient conditions) to enclose the manifold in a chamber which can be purged with dry air, thus limiting the effects of ingress.



Relative Humidity and Temperature

There are two different approaches to calibrating relative humidity sensors.

One approach is to place the sensors directly into a calibration 'chamber', which is a temperature and humidity controlled self-contained environment. This functions in a similar way to a climatic chamber, only on a much smaller scale and with much greater uniformity. Calibration chambers without temperature control also exist, meaning that the selected relative humidity will be generated at the prevailing ambient temperature however, it is important to ensure that when these types of generator are used, they are placed into an environment with a stable temperature.

S904/OptiCal Calibration Chamber

The second approach is to use an external dew-point generator to pass a flow though a manifold into which the sensors are mounted. The manifold is placed inside a larger, temperature controlled chamber.

The advantages of this second approach are:

- The volume of the manifold is quite small, and there are few ingress points, so step changes tend to happen more quickly.
- Using a volumetric mixing dew-point generator allows much lower humidities to be achieved compared with a calibration chamber.

The disadvantages are:

- The components involved are physically much larger.
- They can be significantly more expensive than a self-contained chamber.



Measurement Range

The next deciding factor is measurement range. The questions to ask here are:

- What is the complete operating range of your devices? (Also consider temperature range if the probes in question are measuring relative humidity).
- Do you need to calibrate across the complete range, or do you have a specific area or areas of interest?

Relative Humidity

The range of an RH calibration system depends on the ability to control two separate parameters: the temperature range of the chamber and the relative humidity range (the lowest RH point being the limiting factor in most cases).

All Michell relative humidity chambers (S904, OptiCal) are capable of drying their internal volumes to just 10% RH at any temperature within their operating range. It is challenging to dry a comparatively large volume below this point, as the system is simply extracting the air, drying it with a desiccant cartridge and re-injecting it with a slightly lower moisture content. It is possible to humidify the chamber up to 90% RH which, generally speaking, is a sensible limit set for the purpose of preventing condensation. If condensation should occur, it would take a long period of time (and a significant strain on the desiccant cartridge) to dry the chamber out again.

The Michell Instruments' HG10 uses an external humidity generator to feed a stream of air, with a precisely controlled humidity, directly into a manifold within a temperature controlled chamber. The humidity generator is fed with fresh dry air from a pressure swing dryer, and can achieve very low humidities at a specific temperature, with a total range of 1 to 95% RH.

Dew Point

Dew-point calibration systems generally produce much lower absolute humidities than RH calibration systems. The generation range of dew-point systems depends on two factors:

- The output dew point of the pressure swing dryer used to provide the dry air source to the humidity generator (sometimes referred to as 'full dry').
- The resolution of the dew-point generator—which is its ability to mix specific quantities of full dry and saturated air together, in stages, to achieve accurate outputs of very low moisture content. Where volumetric flow mixing generators are concerned; the more stages of mixing, the lower the dew point the generator can control to. For example, a single stage DG3 can only control to a minimum dew point of approximately -40°C (-40°F), no matter how dry the input air is; whereas a two stage DG2 can generate dew points to -75°C (-103°F). Three stages of mixing give the capability to generate dew points to -100°C (-148°F).



Calibration Technology

Air Sources

Michell Instruments' dew-point calibration systems require clean and dry compressed air to operate correctly. The required specification of this air varies depending on the model of pressure swing dryer selected, but typically it should be at a pressure of approximately 7 barg (100 psig). For calibration systems designed to generate $<-80^{\circ}C$ ($<-112^{\circ}F$) dew point (generally those utilizing the PSD4), the supply air will need to be pre-dried to $<-40^{\circ}C$ ($<-40^{\circ}F$) dew point, in order to maximize the effectiveness of the pressure swing dryer.

For users who do not have a supply of compressed, or instrument air readily available on site, Michell Instruments can provide compressors suited to each type of system, and a pre-dryer for use with systems designed for <-80°Cdp (-112°Fdp) capability. See the PSD2 & PSD4 datasheet and the related order codes section for details.

Pressure Swing Dryers

Michell Instruments' air dryers operate on the 'pressure swing' principle. Two desiccant columns are connected to each other in parallel. Compressed air from the dryer inlet is passed through the first desiccant column to remove virtually all of the moisture present. The majority of the dry air from this column is partially expanded to further reduce the dew point and then directed to the dryer outlet. The remaining dry air is used to purge the second, off-line desiccant column to sweep away the moisture it collected during its on-line cycle to the atmosphere.

After a pre-determined period of time, the function of the two columns is switched - the first column is re-generated while the second column is on-line, producing a flow of dry air. As part of the changeover, the off-line column is rapidly de-pressurized which causes the moisture adsorbed by the desiccant to be released and purged away. One cycle of this operation is represented diagrammatically in *Fig. 2*.




Fig. 2. One dryer cycle of the PSD2

The dryers require minimal maintenance and, under normal operating conditions, only require a desiccant change approximately once every 5 years. The highly efficient purge/regenerate system enables the dryer to operate at the same high performance levels throughout the lifetime of the desiccant.

There are two models of dryer in Michell's PSD range:


- The PSD-2 gives an output of -80°C (-112°F) dew point air or better.
- The PSD-4 gives an output of -100°Cdp (-148°Fdp) or better (the PSD-4 requires an input source of dry instrument or calibration air of -40°Cdp (-40°Fdp).



Dew-Point Generators

The DG Series dew-point generators are based on the volumetric mixing of dry and wet gases. This gives the fastest response when changing between set points when compared to other dew-point generation technologies, (such as two-temperature, two-pressure or the combination of both). The mixing is either controlled by flow metering valves for a manual control of the target dew point, or automated using a bank of preset metering valves, selected by actuating combinations of solenoids to switch between the different wet-dry mixing ratios.

A dry gas source is fed to the generator from a pressure swing dryer, and split into two streams. One stream is bubbled through liquid water via a sintered glass nozzle, ensuring it is completely saturated with water vapor, while the other stream remains dry. The two gas streams are then mixed at atmospheric pressure, in a single or multi-stage process to generate the target humidity level. The entire enclosure is insulated and temperature controlled ensuring the saturation, and therefore the output, is always consistent.



Flow diagram for DG2 showing mixing stages

A single stage of mixing provides a coarse adjustment, limited to around -40°Cdp (-40°Fdp). In order to generate drier dew points the output of this first stage, is mixed with the dry gas source a second time, providing finer adjustments for low moisture concentrations down to -75°Cdp (-103°Fdp). For trace moisture levels, a third stage can be added, where the output of the second stage is again mixed with the dry gas source, giving the possibility to generate dew points as low as -90°Cdp (-130°Fdp). The -100°C (-148°F) dew point is taken directly from the output of the dryer.

Manual Mixing – DG2 & DG3

The DG3 with manual single-stage mixing has the ability to generate dew points ranging from -40 to +20°Cdp (-40 to +68°Fdp). Drier dew points, down to -75°Cdp (-103°Fdp), can be reached by the DG2 which has a second stage of gas-flow mixing. The great strengths of the DG2 and DG3 are their ease of use and flexibility in manually generating an accurate target dew point by fine tuning the gas mix via the flow metering valves. A table of nominal flows is supplied with the generator to guide the user in setting the metering valves appropriately for each desired set point.

Automatic Mixing – DG4

The DG4 uses a two-stage flow mixing system with calibrated needle valves controlled by solenoid drivers to mix dry air and saturated air in precisely pre-metered proportions. This allows the operator to generate a range of dew-point levels from -75 to +20°C (-103 to +68°F). The exact number of presets can be specified at the time of order (normally, 11 are chosen), giving +10°Cdp (+18°Fdp) intervals across the range. The generator can be driven by computer software, the RS232 interface, or via the front panel manual override switches.

Automatic Mixing – VDS

In order to generate dew points down to -100°C (-148°F), a more sophisticated system is required. The software controlled Vapor Delivery System (VDS) generator gives precise, repeatable and flexible control of the generated dew point. Individual, three-stage, mass flow controllers select precise proportions of wet and premixed air. Humidity injection is achieved by a liquid mass flow controller and controlled evaporation system. The entire system is controlled by dedicated PC software, allowing automatic calibration programs to be created, or set points to be triggered manually.



Control

There are **three options of set point control**, which vary between models. This is an important factor to consider, as some systems may have a greater requirement for automation.

This is especially applicatory if the system is being designed to calibrate a large volume of sensors:

- Manual flow mixing (DG3, DG2) The wet and dry flows are manually altered by metering valves on the front panel of the generator. On the DG2 these are monitored by means of a flow meter for each valve. A table of nominal flow values for each set point is provided, and full analog adjustability is possible across the complete range of the device.
- Locally controlled automatic flow mixing (DG4) The generator is supplied with a number of user-defined (at the time of order) humidity set points (minimum of 4, including full dry, maximum of 11), which are selected by means of buttons on the front panel.
- Remote controlled automatic flow mixing (DG4, VDS3) Control is implemented by sending serial commands to the generator via RS232, or USB, either through dedicated control software (which can run user-defined sequences), or via the customer's own system.

Reference Instrument

Michell Instruments' chilled mirror hygrometers are precision instruments for critical measurement and control applications. Chilled mirror sensors measure a primary characteristic of moisture - the temperature at which condensation forms on a surface.

This means that chilled mirror instruments:

- Have no drift: the temperature at which condensation forms is measured directly so there are no calculated variables that could shift over time.
- Are inherently repeatable, giving reliable results every time.


Chilled Mirror Operation

The chilled mirror sensor consists of a temperature controlled mirror and an advanced optical detection system.

A beam of light from an LED is focused on the mirror surface with a fixed intensity. As the mirror is cooled, less light is reflected due to the scattering effect of the condensate formed on the mirror surface. The levels of reflected and scattered light are measured by two photo-detectors and compared against a third reference detector measuring the intensity of light from the LED.

The signals from this optical system are used to precisely control the drive to a solid state thermoelectric cooler (TEC), which heats or cools the mirror surface. The mirror surface is then controlled in an equilibrium state whereby evaporation and condensation are occurring at the same rate. In this condition the temperature of the mirror, measured by a platinum resistance thermometer, is equal to the dew-point temperature of the gas.

In the S8000 RS and S4000 TRS, an auxiliary cooling system is used to remove heat from the 'hot' side of the TEC. This supplements the depression capabilities of the heat pump, and enables measurement of very low dew points.





Choosing a Reference Instrument

The two most important considerations when choosing an appropriate reference instrument for performing traceable, credible calibrations are accuracy, and measurement range. As explained earlier in this guide, the accuracy of the reference should ideally be better than the accuracy of the units under calibration. Measurement range should be chosen to match the generation range of the operators humidity generation equipment.

Michell Instruments' range of chilled mirror reference hygrometers have measurement capabilities matched to the performance of each of the different RH and dew-point generator options.

When using a chilled mirror reference to perform relative humidity calibrations, it is necessary to calculate relative humidity from dew-point, and therefore a measurement of ambient temperature is also required.

The actual formula used is: $RH\% = \frac{e}{e_s} \times 100$

Vapor pressure (*e*) is determined by solving the Sonntag (1990) formula for the current dew-point temperature, and saturation vapor pressure (*es*) is found by repeating the process for the ambient temperature.

This calculation is recognized and published in the National Physical Laboratory's 1996 publication 'A Guide to the Measurement of Humidity'. Its use will, in most cases, still yield lower uncertainties of measurement than can be achieved with hygrometers which directly measure relative humidity.

Calibration

Although Michell Instruments' chilled mirror hygrometers are fundamental and do not drift, in order to maintain the traceability of your reference it is advisable to return it to Michell Instruments to be calibrated against one of our transfer standards on an annual basis.

Manifold

Standardized or customized designs of manifold are available for Michell Instruments' sensors depending on how many sensors are intended to be calibrated on the system at any one time. Manifolds to accept non-Michell sensors or instruments can also be custom designed; the optimal configuration can be designed from the dimensions of the device and its mounting arrangement.


Integration

Integration of the system components, such as logging of sensors under test, the reference instrument and other further enhancements, can be realized. Please contact a Michell Instruments' representative for further details.



Calibration System Selection Guide

The following flow chart is designed to aid the process of selecting an appropriate calibration system:



* Typical range, dependent on customers specification at time of order





Our sophisticated range of calibration instruments and integrated systems can provide traceable calibration of humidity sensors in your own laboratory

Calibration Instruments

Technical Specifications & Detailed Information

Pressure Swing Dryers

Pressure Swing dryers provide a source of very dry compressed air for use as a zero gas in humidity calibration systems, or for general laboratory applications.

PSD2 & PSD4 Pressure Swing Dryers





The Michell PSD Series Pressure Swing Dryers use two columns filled with 4Å molecular sieve desiccant, which are used alternately on a two-minute switching cycle. The PSD dryers are designed to operate continuously, using a small proportion of the dried air, to regenerate the offline column — generally giving desiccant life in excess of five years. This type of heatless regeneration also uses significantly less energy than a 'heated' type of dryer.


The PSD2 is fitted with inlet and outlet pressure regulation, and delivers up to 7 Nl/min (14.8 scfh) of dry air at 1ppmv or better.

The PSD4 is supplied with stainless steel internals and larger volume desiccant columns. These factors, combined with high integrity VCR couplings, deliver an output of up to 90 NI/min (optional) at better than $13ppb_{vr}$.


Highlights

- Excellent long term stability
- Maintenance-free except for a desiccant change once every 5 years
- Completely self-contained
- Low power consumption

Dimensions - PSD2



Dimensions - PSD4



Depth: 270mm



Pressure Swing Dryers

Technical Specifications

Model	PSD2	PSD4-STD (Standard)	PSD4-HFV (High flow volume)	PSD4-HPO (High pressure output)
Performance				
		Gas	output	
Flow	7 NI/min (14.8 scfh)	30 NI/min (63.6 scfh)	90 NI/min (109.7 scfh)	30 NI/min (63.6 scfh)
Pressure		0.5 barg (7 psig)		User-settable up 8 barg (116 psig)
Moisture content	<1ppm _v		<13ppb _v	
Input Requireme	ents			
		Gas	supply	
Flow	10 NI/min (21.2 scfh)	30 NI/min (63.6 scfh)	90 NI/min (109.7 scfh)	30 NI/min (63.6 scfh)
Pressure	5 to 7 barg (70 to 100 psig)		6 to 10 barg (87 to 145 psig)	
Moisture content	Oil and liquid water-free		<16ppm _v	
Electrical Input				
Power		100 to 115 OR 220	0 to 240 VAC, 50/60Hz	
Power connection		IEC (3 pin female c13) input socket		
Environmental C	onditions			
Operating temperature	+5 to +35°C (+41 to +95°F)		+10 to +40°C (+50 to +104°F))
Storage temperature	-40 to +35°C (-40 to +95°F)	-40 to +50°C (-40 to +122°F)		
Mechanical Spec	ifications			
Туре		Twin column desi	ccant, pressure swing	
Desiccant		4 Ångström Molecula	ar sieve bead (4-8 mesh)	
Timer		Moto	rized cam	
		Gas co	onnections	
Inlet	Swagelok [®] 1/4"		1/4" VCR Swagelok®	
Outlet	Swagelok [®] 1/4"	1/4" VCR Swagelok®	1/2" VCR Swagelok®	1/4" VCR Swagelok®
		F	ilters	
Outlet	None	Millipore Wafergard IIF Micro In	line (sealed type) with PTFE mem retention of 0.003µm particles	brane element rated at >99.999%
Vent	None	Bonded glass mice	rofiber rated at >99.999% retention	on of 0.1µm particles
Construction	Rack mount: 19" x 6U x 324mm (12.8")	GRP wall mounting enclosure: 735 x 535 x 270mm (29 x 21 x 10.5")		
Weight	12.5kg (27.5lbs)	25kg (55lbs)	30kg (66lbs)	26kg (57lbs)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: PSD2 and PSD4_97160_V3_UK_0815

Dew-Point Generators

The Michell range of dew-point generators provides flexibility and control at a competitive price. Based on the volumetric mixing of dry and wet gases, the instruments can be controlled either manually or automatically to suit a wide range of calibration applications.

Generator Overview

Feature	Product	DG3	DG2	DG4	VDS3
Generation ra	inge	-40 to +20°Cdp (-40 to +68°Fdp)	-75 to +20°Cdp (-103 to +68°Fdp)	-75 to +20°Cdp (-103 to +68°Fdp)	-95 to +20°Cdp (-139 to +68°Fdp)
Temperature	controlled	Yes	Yes	Yes	Yes
Control metho	od	Manual Mixing	Manual Mixing	Automatic – Local or Remote control	Automatic – Remote control

DG3 Dew-Point Generator



The DG3 is our entry-level, single-stage mixing humidity generator. It is operated by manually mixing the two gas streams using flow control valves. The DG3 provides flows up to 5 Nl/min (10.6 scfh) and generates dew points ranging from -40 to $+20^{\circ}$ Cdp (-40 to $+68^{\circ}$ Fdp). Infinite mixing is achievable within its working range.

Highlights

- Consistently dry output over long time periods
- Full analog control of generated dew points across -40 to +20°Cdp (-40 to +68°Fdp) operating range
- Generated output responds quickly to a change of set-point
- Stable humidity generation
- Compact packaging

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DG3_97334_V1_UK_0613




Technical Specifications

Mixing stages	1 stage
Humidity range	-40 to +20°Cdp (-40 to +68°Fdp)
Gas supply	6 NI/min (12.7 scfh) air @ 0.75 barg (11 psig) and -75°Cdp (-103°Fdp)
Gas output	1 to 5 Nl/min (2.1 to 10.6 scfh) air @ 0.5 to 1 barg (7 to 15 psig)
Filter	Particulate filter
Saturator	Polycarbonate and porous polyethylene sinter
Heating	Finned heating elements, 500 watts, fan circulation
Power supply	220 to 240 V, 50Hz or 100 to 120 V; 60Hz
Storage temperature	+5 to +40°C (+41 to +104°F) (with saturators empty)
Operating temperature	+18 to +24°C (+64 to +75°F)
Enclosure size	19" sub-rack x 6U high x 340mm (13.4") deep
Weight	9kg (20lbs)

Generator

-

Dimensions



20

DG2 Dew-Point Generator



The DG2 has two stages of gas-flow mixing which allow it to generate dew points down to -75°Cdp (-103°Fdp). The great strengths of the DG2 are its ease of use and its flexibility in manually generating an accurate target dew point by fine tuning the gas mix via its flow metering valves. Infinite mixing is achievable within its working range.

Highlights


- Operation range of -75 to +20°Cdp (-103 to +68°Fdp) suiting the vast majority of calibration requirements
- Simple operation through manual flow mixing
- Flexibility in generating precise target dew-point temperature
- Generated output responds quickly to a change of set-point
- Stable humidity generation

Technical Specifications

Mixing stages	2 stage
Humidity range	-75 to +20°Cdp (-103 to +68°Fdp)
Gas supply	8 NI/min (17 scfh) -1 air @ 1 barg (11 psig) and -75°Cdp (-103°Fdp)
Gas output	1 to 5 Nl/min (2.1 to 10.6 scfh) (dependent on set point) @ ATM $% \left(\left(\frac{1}{2}\right) \right) =\left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\left(\frac{1}{2}\right) \right) \left(\frac{1}{2}\right) \left(\frac{1}{2$
Filter	Particulate filter
Saturator	Polycarbonate and porous polyethylene sinter
Heating	Finned heating elements, 500 watts, fan circulation
Power supply	220 to 240 V, 50Hz or 100 to 120 V; 60Hz
Storage temperature	+5 to +40°C (+41 to +104°F) (with saturators empty)
Operating temperature	+18 to +24°C (+64 to +75°F)
Enclosure size	19" sub-rack x 12U high x 400mm (15.8") deep
Weight	20kg (44lbs)

Generato

Dimensions



Depth: 400mm

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DG2_97333_V1_UK_0613

www.michell.com



DG4 Dew-Point Generator



The DG4 is a two-stage push-button dew-point generator which operates in the range of -75 to $+20^{\circ}$ Cdp (-103 to $+68^{\circ}$ Fdp). It can be delivered with between 3 and 10 factory-set dew point settings, selectable from the front panel keypad. Its RS232 communication port enables set points to be selected remotely by a PC or other device. The DG4 offers maximum flexibility via its preset values combined with optional manual mixing above -40°C (-40°F) dew point.

Highlights


- Operation range of -75 to 20°Cdp (-103 to +68°Fdp) suiting the vast majority of calibration requirements
- Simple operation through push-button switching of set points
- Remote control via RS232 comms
- Generated output responds quickly to a change of set point
- Stable humidity generation

Technical Specifications

Mixing stages	2 stage
Humidity range	-75 to +20°Cdp (-103 to +68°Fdp)
Gas supply	8 NI/min (16 scfh) (max) @ 0.7 barg / 11 psig and -75°Cdp (-103°Fdp)
Gas output	1 to 5 NI/min (2.1 to 10.6 scfh) (dependent on set point) @ ATM
Filter	Particulate filter
Saturator	Polycarbonate and porous polyethylene sinter
Heating	Finned heating elements, 300 watts, fan circulation
Power supply	220/240V, 50Hz or 100/120V; 60Hz
Storage temperature	+5 to +40°C (+41 to +104°F) (with saturators empty)
Operating temperature	+18 to +24°C (+64 to +75°F)
Enclosure size	19" sub-rack x 6U high x 330mm (13") deep
Weight	25kg (55lbs)

Generato

Dimensions



Depth: 330mm

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DG4_97335_V2_UK_0315



VDS3 Dew-Point Generator



The VDS3 is a sophisticated computer-controlled dewpoint generator that operates in the range of -100 to +20°Cdp (-148 to +68°Fdp). Individual three-stage mass flow controllers select precise proportions of wet and pre-mixed air. Humidity injection is achieved by a liquid mass flow controller and controlled evaporation system. The Vapor Delivery System (VDS) gives repeatable and flexible control of the generated dew point and can be programmed with up to 13 presets that can be activated manually or as part of an automatic calibration program.

Highlights


- Operation range of -100 to +20°Cdp (-148 to +68°Fdp) suiting the calibrated range of almost all dew-point sensors
- Fully automated remote control
- Mass flow controlled mixing of wet and dry flows ensures complete repeatability of set-points
- Generated output responds quickly to a change of set-point
- System optimized for excellent output stability (±0.5°C / ±0.9°F)

Technical Specifications

Dew-point range	-100 to +20°Cdp (-148 to +68°Fdp) (factory default preset values= -100, -90, -80, -70 -60, -50, -40, -30, -20, -10, 0, +10 and +20°C (+68°F))
Output stability	±0.5°C (±0.9°F)
Required gas supply	30 Nl/min (63.6 scfh) @ 4.8 barg (70 psig) pressure and <13.8 ppb_v (-100°C / -148°F atmospheric dew-point) moisture content, or 90 Nl/min (190.7 scfh) for high-flow output version
Gas output	10 NI/min (21.2 scfh) @ 0.5 barg (7.3 psig) or 30 NI/min (63.6 scfh) for high-flow output version
Cable connection	USB (type B) for PC Control RS485 (9 way D plug) for Setup
Water reservoir	Material= ABS Capacity= 1 liter
Power supply	220 to 240 V AC or 100 to 120 V AC 50/60 Hz
Power consumption	500 Watt maximum
Power connector	3 pin IEC
Power supply fuse	3A (F) quick blow
Operating temperature	+10 to +40°C (+50 to 104°F)
Construction	Painted diecast aluminum enclosure with smoked glass door
Dimensions	1020 x 555 x 600mm (40 x 22 x 24") h x w x d
Weight	65kg (143lbs) maximum

Generato

Dimensions



Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: VDS3_97336_V1.2_UK_0716




How Does Chilled Mirror Technology Work?

The Chilled Mirror sensor consists of a temperature-controlled mirror and an advanced optical detection system.



Michell Instruments S8000 sensors utilize our **RRS Optical System** to guarantee 0.01°C sensitivity and the fastest dynamic response to dew points as low as –90°C. The system employs active monitoring and adjustment to automatically rebalance the optics to accommodate any changes in the signal level not associated with condensed moisture.



A beam of light from an LED (1) is focused on the mirror surface (2) with a fixed intensity. As the mirror is cooled, less light is reflected due to the scattering effect of the condensate formed on the mirror surface. The levels of reflected and scattered light are measured by two photo-detectors (3 & 4) and compared against a third reference detector (5) measuring the intensity of light from the LED.

The signals from this optics system are used to precisely control the drive to a solid state thermoelectric cooler (TEC) (6), which heats or cools the mirror surface. The mirror surface is then controlled in an equilibrium state whereby evaporation and condensation are occurring at the same rate. In this condition, the temperature of the mirror, measured by a platinum resistance thermometer (7), is equal to the dew-point temperature of the gas.

In the **S8000 RS**, and **S4000 TRS**, an auxiliary cooling system is used to remove heat from the "hot" side of the TEC. This supplements the depression capabilities of the heat pump, and enables measurement of very low dew points.





Chilled Mirror Product Comparison Table

Product	Dew-Point Measurement Range from 20°C Ambient (°C)	Maximum Measureable Dew Point (°C)	Minimum Measurable Dew Point with Additional Cooling (°Cdp)	Accuracy (°C)	Integrated Auxiliary Cooling	Sensor Location
Optidew Vision	-40/+20 (-40/68°F)	+130 (+266°F)	-40 (-40°Fdp)	±0.2 (0.36°F)	No	Remote
S4000 Climatic	-55/+20 (-67/+68°F)	+85 (+185°F)	-80 (-112°Fdp)	±0.1 (±0.18°F)	No	Remote
S4000 TRS	-100/+20 (-148/+68°F)	+20 (+68°F)	Not applicable	±0.1 (±0.18°F)	Yes	Integral
S8000 Remote	-40/+20 (-40/+68°F)	+90 (+194°F)	-50 (-58°Fdp)	±0.1 (±0.18°F)	No	Remote
S8000 Integrale	-60/+40 (-76/+104°F)	+40 (+104°F)	Not applicable	±0.1 (±0.18°F)	No	Integral
\$8000 RS RS80	-80/+20 (-112/+68°F)	+20 (+68°F)	Not applicable	±0.1 (±0.18°F)	Yes	Integral
RS90	-90/+20 (-130/+68°F)	+20 (+68°F)	Not applicable	±0.1 (±0.18°F)	Yes	Integral



Optidew Vision Optical Dew-Point Meter



The Optidew Vision precision dew-point meter is based on the proven, fundamental optical dew-point measurement principle, giving long-term drift-free performance. It offers a wide measurement range from the equivalent of <0.5 to 100% RH at ambient temperature (dew point range: -40 to +90°C (-40 to +194°F), and up to +130°C (+266°F) with high temperature option).

As a calibration reference

The Optidew is an excellent entry level calibration reference, supplied as standard with a fully traceable inhouse calibration or optional UKAS-certified calibration. Its simple operation makes it possible for anyone to use with minimum training. Simply connect the instrument, power it up and measurement will begin automatically.

Data communication and application software

The instrument provides two linear 4-20 mA outputs and RS232 or RS485 serial communications, allowing configuration and monitoring by a suitable computer, data logger or other device. The comprehensive application software provides an interface to configure and control instrument functions, and enables all measured and calculated parameters to be graphed or logged over time.

Frost assurance technology (FAST)

Super-cooled water can exist at temperatures down to -30°C (-22°F), and when formed on the mirror of a chilled mirror hygrometer can introduce errors of up to 10% in reading. All Michell Chilled Mirror products feature FAST, the frost assurance technology that guarantees all dew-point measurements below 0°C (+32°F) are made over ice. The FAST system works by rapidly cooling the mirror until a film of ice has formed on the mirror of pre-determined thickness – once ice has been formed, control returns to the instrument and measurement can begin.

Compact and convenient package

The bench-top enclosure for the Optidew Vision has a handle that doubles as a stand. An optional panelmounting kit is also available for 19" rack mounting. A bright and clear 2-line vacuum fluorescent display on the front panel enables the instrument parameters to be monitored even when not connected to the application software.

Highlights

- Fundamental drift-free dew-point measurement
- Convienient, transportable package
- ±0.2°Cdp (±0.36°Fdp) accuracy; optional higher accuracy available
- High temperature sensor option to +130°C (+266°F)
- NEMA-12 bench-top housing
- Display and output of multiple engineering units
- High pressure sensor option to 25 MPa (250 barg / 3626 psig)



Optidew Vision


Technical Specifications

Performanc	е				
Measurement accuracy	$\pm 0.2^{\circ}Cdp$ (±0.36°Fdp), ±0.15°Cdp (±0.27°Fdp) accuracy optional, ±0.1°C (±0.18°F) temperature				
Measurement units	°C, °F dew point; %RH; °C, °F temperature; g/m³; g/kg; $a_{w}^{}; \Delta$ (t – t dew point)				
Response speed	1°C/sec (1.8°F/	/sec) plus settling	g time (dew poin	t dependant)	
Power supply		or 127 to 370 V , 4A quick blow	DC, 47 to 440 H	z, 20 W max,	
Dew-Point S	Sensor				
Sensor	1-Stage	2-Stage	High Temp PEEK	Climatic or Aluminum head	
Dew-point range	-30°Cdp @ sensor temp of +20°C +90°Cdp @ sensor temp of +90°C	-40°Cdp @ sensor temp of +20°C +90°Cdp @ sensor temp of +90°C	-40°Cdp @ sensor temp of +20°C +130°Cdp @ sensor temp of +130°C	-10°Cdp @ sensor temp of +20°C +130°Cdp @ sensor temp of +130°C	
Temperature range	-40 to +90°C (-40 to +194°F)	-40 to +90°C (-40 to +194°F)	-40 to +130°C (-40 to +266°F)	-40 to +130°C (-40 to +266°F)	
%RH range	<2 to 100%	<0.5 to 100%	<0.5 to 100%	10 to 100%	
Min measured dew point @ +20°C	-30°C -40°C -40°C -10°C (-40°F) (+14°F)				
Mirror material options	Gold plated cop stud**, platinu	oper (standard), g m stud**	gold stud, 316 st	ainless steel	
Sensor body material options	Acetal (standard), high temperature PEEK, 316 stainless steel**, anodized aluminum**				
Temperature measurement	4 wire Pt100, 1/3 DIN class B				
Sample flow	0.1 to 2 NI/min (0.2 to 4 scfh) (in sampling block)				
Maximum velocity	10 m/sec direct insertion, 30 m/sec with sintered guard				
Pressure	Standard unit: 2 Mpa / 20 barg (300 psig) (max), ingress protection: IP66 High Pressure version: 25 Mpa / 250 barg (3626 psig) (max), ingress protection: IP65				
Sensor cable	temperature High tempera	Standard cable: PVC insulator material, +70°C (+158°F) max			
Cable length	2m (6.56'); 50r	n (164'); up to 2	50m (820′) on sp	pecial request	


Remote PR	Г
Temperature measurement	4 wire Pt100, 1/10 DIN class B
Remote PRT cable	Standard cable: PVC insulator material, +70°C (+158°F) max temperature High temperature cable: PTFE insulator material, +250°C (+482°F) max temperature
Cable length	2m (6.56'); 50m (164') max; up to 250m (820') on special request
Transmitter	Electronics
Resolution	0.1 for °C, °F and %RH, 0.01 for g/m ³ and g/kg
Outputs	Analog: 4–20 mA or 0–20 mA over user-settable output, Accuracy: $\pm 0.2^{\circ}C$ ($\pm 3.6^{\circ}F$); 500 Ω maximum load resistance Digital: RS232 @ 9600 baud rate Alarm: Volt free contact, max 2 A @ 30 V DC, 0.5 A @ 120 V AC
Status LEDs	DCC/Alarm Status
Operating temperature	-20 to +50°C (-4 to +122°F) ambient
Environmental conditions	Up to 98% RH non-condensing
Enclosure	Standing case with carry handle, panel mounting kit optional
Ingress protection	IP54 (NEMA 2)
Cable pack	Mains, RS232 cable and output connector
General	
Calibration	4-point traceable in-house calibration as standard, UKAS accredited calibrations optional — please consult Michell

Dimensions

Front View



Front View with Panel Mount Kit



Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: Optidew Vision_97144_V6_UK_1115

.

S8000 Chilled Mirror Series Features

As the largest dew-point sensor manufacturer in Europe we know how important it is to have an accurate and reliable calibration reference. Our S8000 Series of chilled mirror reference hygrometers provide extremely accurate and precise measurement of dew point, relative humidity and temperature and are constantly in use in our own production environment, 24/7 calibration facility and service center. Michell's 40 years of expertise in the field of moisture measurement is built into each and every chilled mirror hygrometer design and our technical experts are always on hand to provide support and advice where needed.

Supplied with Traceable Calibration


Chilled mirror is free from temperature dependence and remains accurate and drift-free across the entire measurement range. The S8000 Series of instruments are delivered fully calibrated and traceable to NPL and NIST national standards through Michell's world class UKAS accredited humidity calibration laboratory.




Frost Assurance

All S8000 Series instruments feature FAST, the frost assurance technology that forces ice formation on the mirror so all dew-point measurements made below 0°C (+32°F) are guaranteed to be 'over ice'. The FAST system works by rapidly cooling the mirror until a film of ice has formed on the mirror of pre-determined thickness – once ice has been formed, control returns to the instrument and measurement can begin.

A viewing microscope is also available for the S8000 Integrale and S8000 RS. This enables the user to inspect the mirror surface during the measurement process, enhancing confidence in the formation of the correct phase of water condensate (dew or frost) on the mirror surface and therefore measurement accuracy.







Display & Outputs

A clear, bright and highly visible LCD display is capable of showing any three user-selectable parameters in large clear text. The display also features a stability graph and displays the operational status of the unit. An easy to use menu system enables the operating parameters of the instrument to be quickly customized to suit the target application. The S8000 Series also comes with customizable analog outputs and one or more alarms, enabling integration into an existing process or automated test and calibration system.



Built-in Data Logging

A sophisticated logging system provides the facility to log the values of all the instrument parameters at operator specified intervals. The log files are saved directly onto a removable SD memory card (supplied), allowing the logs to be easily transferred to a PC for analysis or correlation with test results.



Application Software

S8000 Series instruments feature a digital communications port (USB, RS232, RS485, Modbus or Ethernet options, depending on model) and multiple analog outputs, allowing configuration and monitoring by a suitable computer, data logger or other device. Adjustable isolated alarm contacts allow the S8000 Series to be used for direct process control.

Comprehensive application software is supplied with our chilled mirror hygrometers free of charge, to provide an interface to configure and control instrument functions, and enable all measured and calculated parameters to be graphed or logged over time.

Preser Bine	Market Sector	- <u>p</u>		CC all Presentation Star			
Ire part	-8.05	°C	Refailer hereit	0.16	%Rh	Reschate task Presses Gener	
Impered	120.00	0 °C	Water contract	3056.24	ppmV	0 0 0 0	
These	261.0	ml/m	-	376.990	ppmŴ	DCC	
Pressante	0.0	Bara	Alexandra .	1.90	g/Kg	Control	
Tanganak	21.2	°C	Tradamantipes;	2.53	g/mੈ	00:01:24	
-							
5000 -							
2000							alland alland Tanga - Ne



S8000 Integrale

Precision Chilled Mirror Hygrometer



The S8000 Integrale is the base model of the S8000 Series and is suitable for a range of calibration applications. The integrated sensor head enables the S8000 to function as a stand-alone instrument, allowing measurement to -60°Cdp (-76°Fdp).

The hygrometer provides a direct measurement of dew point, temperature and pressure. Dew-point measurement is based on the proven, fundamental optical chilled mirror measurement principle, giving long-term drift-free humidity measurement over the entire operating range. The S8000 uses this measurement to offer a range of available measurement units including ppm_v absolute humidity, relative humidity and ppm_v.

To further improve the accuracy of pressure-derived calculated values ($ppm_{v'} ppm_{w'}$ absolute humidity), an optional internal pressure transducer can be supplied, which provides real-time pressure. This allows for continued humidity measurement stability even during fluctuations in sample pressure.

A pair of adjustable isolated alarm contacts allow the S8000 Integrale Chilled Mirror Hygrometer to be used for direct process control. A high-contrast touch screen LCD display provides entirely customizable local indication of the measured values, along with a trend graph and fault warnings.

Highlights

- ±0.1°Cdp (±0.18°Fdp) accuracy
- Fundamental, accurate and drift-free measurement
- Simple configuration and operation via touch screen interface
- Precision measurements to -60°C (-76°F) dew point
- FAST guaranteed frost formation below 0°C (+32°C)
- Measure at pressures up to 2 MPa (20 barg)
- USB, Ethernet, RS485 or RS232 connectivity
- Datalogging to SD card or via digital comms



Reference

S8000 Integrale

Technical Specifications

Dew-Point Sensor Performance

Measurement technology	Chilled Mirror
Measurement range	-60 to +40°Cdp (-76 to +104°Fdp)
Accuracy	±0.1°C (±0.18°F)
Reproducibility	±0.05°C (±0.09°F)
Operating pressure Low pressure version High pressure version	0 to 1 barg / 14.5 psig 0 to 20 barg / 290 psig
Sample flow rate	0.1 to 1 NI/min (0.2 to 2.1 scfh)
Detection system	RRS Triple Detection

Remote PRT Probe (Optional)

Temperature measurement	4 wire Pt100, 1/10 DIN class B
Measurement accuracy	±0.1°C (±0.18°F)
Cable length	2m (6.6') (250m (820') max)
Flow Sonsor	

Flow Sensor

Measurement accuracy Measurement range

Typical ±5% uncalibrated 0 to 1000 ml/min


Integrated Pressure Sensor (Optional)

Measurement range	0 to 25 bara (0 to 377 psia)		
Measurement accuracy	0.25% Full Scale		
Measurement units	psia, bara, KPa or MPag		
Monitor			
Resolution	User-selectable to 0.001 dependant on parameter		
Measurement units	°C and °F for dew point and temperature %RH, g/m ³ , g/kg, ppm _v , ppm _w (SF ₆), for calculated humidities		
Outputs			
Analog	3 channels, user-selectable 4–20 mA, 0–20 mA or 0–1 V		
Digital	Modbus RTU over USB, and optional Modbus RTU over RS232, RS485 or Modbus TCP over Ethernet		
Alarm	Two volt-free changeover contacts, one process alarm, one fault alarm; 1 A @ 30 V DC		
НМІ	5.7" LCD with touchscreen, white on blue graphics		
Data logging	SD Card (512Mb supplied) and USB interface SD Card (FAT-16) — 2Gb max. that allows 24 million logs or 560 days, logging at 2 second intervals		
Environmental conditions	-20 to +40°C (-4 to +104°F)		
Power supply	85 to 264 V AC, 47/63 Hz		
Power consumption	100 V A		
EMC - Class A Emissions Industrial Location Immunity	Complies with EN61236:1997 (+A1/A2/A3)		

Mechanical Specifications Dimensions 184 x 483 x 368mm (7.3 x 19 x 14.5") h x w x d Weight 11kg (24.3lb) General Process connections Process connections 6mm Swagelok® tube or 1/4" Swagelok® tube Storage temperature -20 to +50°C (-40 to +122°F) Calibration 3-point traceable in-house calibration as standard UKAS accredited calibrations optional — please consult Michell

Dimensions





Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S8000 MKII_97509_V1_UK_Datasheet_1015

S8000 Remote

High Precision Dew-Point Hygrometer



The S8000 Remote has all the great features of the other S8000 Series chilled mirror hygrometers, but with a convenient and compact remote sensor design. The fieldproven sensor boasts upgraded temperature control for extremely accurate dew-point measurement. Coupled with the standard $\pm 0.1^{\circ}$ C (0.18°F) accuracy ambient temperature sensor, it provides fundamentally derived, high precision relative humidity readings necessary for validating the results of environmental tests.

The perfect reference for environmental chambers

The relative humidity in climatic chambers will always deviate from the set point. Even in high precision chambers this deviation is typically between 1-3% RH, which can have a considerable effect on the results of many tests. The S8000 Remote can reduce this uncertainty to just 0.5% RH, depending on set point.

The compact remote sensor takes up minimal space in the chamber and features an open cell design, removing the need for any complex heated sampling arrangements or an external pump. Installing the sensor is simply a matter of placing it in an appropriate position within the chamber, and routing the cable externally to the instrument. An optional aluminum sensor head provides a swift response to changes in temperature, preventing any risks of condensation occurring during rapid transitions between temperature set points.

Highlights

- Fundamental, accurate and drift-free measurement
- Remote sensor
- Open design allows remote sensor to be mounted into a sample flow or simply placed in an environment to be monitored
- -40 to +90°C (-40 to +194°F) dew-point range with 0.1°C (0.18°F) accuracy
- Data logging to USB or SD card
- 'FAST' guarantees frost formation below 0°C (+32°F)
- Sensor operates in pressures up to 20 barg (290 psig)



Reference


S8000 Remote


Technical Specifications

Performance			Outputs
Sensor type	Acetal	Aluminium	
Dew-point range	-40°Cdp @ sensor temp of +20°C to +90°Cdp @ sensor temp of +90°C	-20°Cdp @ sensor temp of +20°C to +90°Cdp @ sensor temp of +90°C	
Operating temperature	-40 to +90°C (-40 to +	194°F)	НМІ
%RH range	< 0.5-100%	< 4.5-100%	
Accuracy	±0.1°C (±0.18°F)		Data langing
Response speed	1°C/sec (1.8°F/sec) plus settling time		Data logging
Reproducibility	±0.05°C (±0.09°F)		
Operating pressure	0 to 20 barg (0 to 290	psig)	Environmental
Remote PRT			conditions
Temperature measurement	4 wire Pt100, 1/10 DIN	class B	Power supply
Accuracy	±0.1°C (±0.18°F)		Power consumption
Cable length	2m (6.6ft) (250m (820f	ft) may)	Mechanical S
Optional Remote Pre	. ,		Dimensions (instrument)
Measurement range	0 to 25 bara (0 to 377	psia)	Dimensions (senso
Accuracy	Accuracy 0.25% Full Sc	ale	Cable length
Measurement units	psia, bara, KPa or MPag	9	Weight
Pressure transducer	1/8" NPT		General
thread			
Monitor			Storage temperatu
Resolution	User-selectable to 0.00 parameter	1 dependant on	Detection system
Measurement units	°C and °F for dew poin %RH, g/m ³ , g/kg, ppm, calculated humidities		Calibration

Outputs	
Analog	3 channels, user selectable 4-20 mA, 0-20 mA or 0-1 V
Digital	PC Communications using Modbus RTU over USB
Alarm	Two volt free changeover contacts, one process alarm, one fault alarm; 1 A @ 30 V DC
HMI	High definition, blue LCD, user-adjustable contrast, menu navigation via five button keypad
Data logging	SD Card (512Mb supplied) and USB interface SD Card (FAT-16) - 2Gb max. that allows 24 million logs or 560 days, logging at 2 second intervals
Environmental conditions	-20 to +50°C (-4 to +122°F)
Power supply	85 to 264 V AC, 47/63 Hz
Power consumption	100 V A
Mechanical Specifica	tions
Dimensions (instrument)	180 x 400 x 320mm (7.1 x 15.7 x 12.5") h x w x d
Dimensions (sensor)	ø45 x 128mm with M36 x 1.5-6g mounting thread
Cable length	2, 5 or 10m (6.5, 16.4 or 32.8ft)
Weight	7.9kg (17.4lbs)
General	
Storage temperature	-40 to +60°C (-40 to +140°F)
Detection system	Single optics detection system with auto adjustment
Calibration	4-point traceable in-house calibration as standard; UKAS accredited calibrations optional - please consult Michell Instruments

Dimensions





Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S8000 Remote_97307_V3_UK_1115



........

S8000 RS

High Precision Dew-Point Hygrometer



The S8000 RS is at the cutting edge of chilled mirror reference technology. The advanced sensor design has been refined over several generations and is accurate, reliable and highly sensitive. A sophisticated auxillary cooling system allows the instrument to precisely measure dry dew points to -90°C (-130°F) (100 ppb_v) with no need for additional, external cooling equipment. Combined with its ± 0.1 °C (± 0.18 °F) accuracy this makes it the most cost-effective and convenient hygrometer in its class.

The S8000 RS comes with all the features you would expect from a modern laboratory instrument including a large touch screen interface, built in data-logging, Ethernet / USB connectivity and dedicated application software. It is also the smallest and lightest of the instruments in its class, weighing just 17kg (37.5lbs), and is suitable for rack mounting.

Improved touch screen display

The S8000 RS features an upgraded display offering touch screen operation and a larger viewing area, while retaining all of the functionality of the original S8000 display. A powerful new menu system optimized for touch screen usage makes configuration of instrument parameters quick and easy.

New sensor head design for uncompromising accuracy

The S8000 RS sensor is optimised for measurement of low dew points, and incorporates a high precision Pt100 to measure the mirror temperature. Combined with a sensitive optical detection system and high integrity internal sampling, featuring welded stainless steel tubing and VCR fittings, this provides $\pm 0.1^{\circ}C (\pm 0.18^{\circ}F)$ accuracy of dew-point measurement and the fastest possible response time to very low dew points.

Reference

To further improve the accuracy of pressure-derived calculated values an optional pressure transducer can be installed, which provides a real-time pressure input for these parameters. This allows for continued measurement accuracy, even during sample pressure fluctuations.

Highlights

- Accuracy of ±0.1°C (±0.18°F)
- Precision measurement to -90°Cdp (-130°Fdp) (100 ppb,) with no need for additional cooling
- Simple configuration and operation via touch screen interface
- Sensor head optimized for fast response to low moisture levels
- High measurement sensitivity
- Microscope for visual inspection of condensate on mirror
- Compact 19" x 4U package for flexibility of installation
- Lightweight at 17kg (37.5lbs) less than half the weight of closest competitor
- Ethernet or USB connections
- SD card datalogging




S8000 RS

Technical Specifications


Dew-Point Sensor Performance Measurement technology Chilled Mirror

Measurement technology	Chilled Mirror	
Measurement range RS80: RS90:	-80 to +20°Cdp (-112 to +68°Fdp) -90 to +20°C dp (-130 to +68°Fdp)	
Measurement accuracy	±0.1°C (±0.18°F)	
Reproducibility	±0.05°C (±0.09°F)	
Mirror	Gold plated copper	
Temperature measurement	4 wire Pt100, 1/10 DIN class B	
Sample flow rate	0.5 to 1 NI/min (1 to 2.1 scfh)	
Sample gas pressure	1 MPa (10 barg / 145 psig) maximum	
Remote PRT		
Temperature measurement	4 wire PT100, 1/10 DIN class B	
Measurement accuracy	±0.1°C (±0.18°F)	
Cable length	2m (250m max) (6.6ft (820ft max))	
Flow Sensor		
Measurement range	0 to 1 NI/min (0 to 2.1 scfh)	

Dimensions



Top View



Optional Integrated	Pressure Sensor		
Measurement range	0 to 1.6 MPa (0 to 16 barg / 0 to 232 psig)		
Measurement accuracy	0.25% full scale		
Measurement units	barg, psig, kPa, MPa		
Cable pack	Supply and USB cables Output connectors suitable for indoor use		
Monitor			
Resolution	User selectable to 0.001°C (0.0018°F), depending on parameter		
Measurement units moisture	°Cdp or °Fdp, % RH, g/m ³ , g/kg, ppm _v , ppm _w (SF ₆)		
Temperature	°C or °F		
Pressure	barg, psig, kPa, MPa		
Outputs Analog: Digital:	Three channels, user selectable 4-20 mA, 0-20 mA or 0-1 V USB and Modbus TCP (over Ethernet)		
Alarm	Two volt-free changeover contacts, one process alarm, one fault alarm; 1 A @ 30 V DC		
НМІ	5.7" LCD with touchscreen, white on blue graphics		
Data logging	SD Card (512 MB supplied) and USB interface. Supports SD Card (FAT-16) - 2Gb max. allows 24 million logs or 560 days logging at 2 second intervals		
Environmental conditions	+5 to +30°C (+41 to +86°F) max 80% RH		
Power supply	85 to 264 V AC, 47/63 Hz		
Power consumption	250 V A		
Mechanical Specifica	ations		
Dimensions	177 x 440 x 550mm (7 x 17.32 x 21.65") (h x w x d)		
Weight	17kg (37.5lbs)		
Sample gas circuit	316 stainless steel		
Sample gas connections Inlet: Outlet:	1/4" VCR 1/4" Swagelok®		
General			
Calibration	5-point in-house calibration, national standards traceable as standard UKAS accredited calibrations optional – please consult Michell Instruments		

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: $8000 RS_97316_V2_UK_0116$



S4000 Series Precision Dew-Point Hygrometers



S4000 TRS

The Michell Instruments S4000 Series of chilled mirror hygrometer is available in two distinct models: the S4000 TRS for very dry dew point measurements to -100°C (-148°F), and the S4000 RC for a dynamic range of wet and dry measurements.

The S4000 Series is supplied with all the standard features of our other chilled mirror hygrometers including dynamic contamination control, a microscope for visual identification of the condensate, RS232 digital communications, and both current and voltage analog outputs.

S4000 TRS

The S4000 TRS is Michell Instruments' industry proven chilled mirror reference hygrometer, offering $\pm 0.1^{\circ}$ C ($\pm 0.18^{\circ}$ F) dew point and temperature accuracy, across a wide range of dew points from -100°C (-148°F) (14 ppb,) to +20°C (+68°F).

The S4000 TRS was selected to provide transfer of the trace humidity standard between the NPL (National Physical Laboratory, London UK) and NIST (National Institute of Standards & Technology, Washington DC, USA), on account of its excellent stability and reproducibility. It is now widely used in calibration and standards laboratories worldwide, in recognition of these characteristics.

S4000 Remote Climatic

S4000 RC

The S4000 Remote Climatic offers the widest range of any of Michell's chilled mirror hygrometers, and is capable of measuring dew points from -85°C to +80°C (-121 to +176°F) It includes the same high quality sensing components as the S4000 TRS and a dew-point and temperature accuracy of $\pm 0.1°C$ ($\pm 0.18°F$) across the range.

The S4000 Remote Climatic features a monolithic sensor block designed for mounting in climatic chambers or other environmental monitoring applications.

Highlights

- 0.1°Cdp (0.18°Fdp) accuracy
- Measurement range: S4000 TRS: -100 to +20°Cdp (-148 to +68°Fdp); S4000 RC: -80 to +85°Cdp (-112 to +185°Fdp)
- Precision 100 Ω 4 wire platinum resistance thermometer
- Dual optics detection system
- Available with VCR couplings for optimum trace moisture sampling (S4000 TRS)
- Dual multi-function LED display with unit indicator




Referenc

S4000 Series

Technical Specifications


Model		S4000 TRS	S4000 RC	
Performanc	е			
Measurement technology		Chilled Mirror		
Measurement ra	nge	-100 to +20°Cdp (-148 to +68°Fdp)	-80 to +85°Cdp (-112 to +185°Fdp)	
Measurement ac	curacy		o (±0.18°Fdp) .8°F) temperature	
Measurement un	iits	°Cdp, °Fdp; °C, °F temperature; % RH, ppm _v , ppm _v , g/m³, g/kg, ppm _w for SF ₆		
Repeatability		Better than	0.1°C (0.18°F)	
Resolution		0.01 (0.	1 for % RH)	
Dew-Point S	Sensor			
Mirror		Gold pl	ated copper	
Dual optics detection	ction	Wide band red LED with dual photo sensors, all system insulated		
Temperature measurement		4 wire Pt100, 1/10 DIN class B		
Sample flow rate	9	0.1 to 0.7 NI/min (0 to 1.5 scfh) (recommended)		
Integrated flown	neter	0 to 1 NI/min (0 to 2.1 scfh)		
Sensor pressure		Atm	ospheric	
Configuration	Configuration		Remote	
Auxiliary cooling		Internal refrigeration	Passive - air cooled	
Remote PRT				
Temperature measurement				
Monitor				
Resolution				
Outputs	Analog: Digital: Logic:	RS232		
Auxiliary input 4-20 mA input for automat pressure transducer 0-0.34 MPa (0 to 3.4 barg / 0 psig) (optional)		pensation to 3.4 barg / 0 to 50		
Operating tempe	Operating temperature 0 to +40°C (+32 to +104°F)		(+32 to +104°F)	
Dimensions		840 x 550 x 620mm (33 x 21.7 x 24.4") (h x w x d) - mini rack	Monitor: 140 x 445 x 467mm (5.5 x 17.5 x 18.4") (h x w x d) Sensor: 230 x 228 x 165mm (9 x 8.9 x 6.5") (h x w x d)	
Weight		85kg (187lbs)	Monitor: 7.5kg (16.5lbs) Sensor: 5.5kg (12.1lbs)	
Power supply	Monitor: Sensor:	100 to 115 or	V AC; 50/60 Hz 220 to 240 V AC; /60 Hz	


S4000 TRS Dimensions



S4000 RC Dimensions







Depth: 165mm

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S8000 TRS_97146_V4_UK_0613

.

. . . .



Integrated Calibration Systems Dew-Point Calibration

HG1 Humidity Calibrator





A low-cost, easy to use, fully integrated system for the calibration of dew-point and relative humidity sensors from 2 to 90% relative humidity, -30 to +20°Cdp (-22 to +68°Fdp).

Operation of the HG1 Humidity Calibrator is based on a simple, yet reliable, principle: a source of dry air is split into two streams, one of which is humidified by bubbling it through a water saturator. The two air streams are then volumetrically mixed to produce an air flow of fixed humidity, dependent upon the mixing ratio selected on the HG1's front panel-mounted flow meters.

The HG1 includes an integrated air pump to draw in ambient air, which is passed through a single column of desiccant. Alternatively, a dry air source, such as instrument air or bottled nitrogen, can be connected to the gas inlet to boost the low-end capability down to -40°C (-40°F) dew point and increase the amount of time before the desiccant requires regeneration.

The HG1 can be supplied with a built-in chilled mirror reference instrument to provide a fundamental measurement of the generated dew point when absolute accuracy is required. The chilled mirror reference sensor is mounted directly into the sample chamber.

The reference instrument comes supplied with a software suite that provides real-time monitoring, charting and logging capabilities via a built-in RS232 communications port.

The HG1's integrated test chamber can accommodate a variety of humidity sensors (dimensions opposite) also, as an alternative to the integrated calibration chamber, the unit is supplied with a gas-outlet feed to supply calibration air to an external manifold or system.

The maintenance of the HG1 is simple. When saturated, the desiccant changes color, indicating that it needs to be regenerated which is done by heating in an oven. The saturator water level is monitored from the rear of the unit and an easy top-up arrangement is provided.

Highlights

- Integrated chilled mirror reference hygrometer
- Straightforward operation
- Allows quick verification tests of humidity sensors
- Transportable




HG1

Technical Specifications


Calibration range	2 to 90% RH (-30 to +20°Cdp (-22 to +68°Fdp)) @ 21°C (69.8°F) ambient	
Reference accuracy	Typically ±2% of reading (% relative humidity), 0.2°Cdp (0.36°Fdp), 0.1°C (0.18°F) ambient temperature (with Optidew reference hygrometer)	
Calibration	Through traceable calibration of integrated Optidew reference hygrometer, to NPL and NIST	
Operating temperature	+10 to +35°C (+50 to +95°F) ambient	
Power	90 to 120V AC @ 60Hz or 220 to 260V AC @ 50Hz	
Calibration chamber	Steel with gasket seal 120 x 120 x 250mm (4.7 x 4.7 x 9.8") (h x w x d)	
Overall dimensions	Painted aluminum case 305 x 520 x 400mm (12 x 20.5 x 15.7") (h x w x d)	
Sample flow rate	4 NI/min (0.85 scfh) for the sensor cell	
Weight	20kg (44lbs)	

Dimensions





Top View



Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: HG1_97158_V2_UK_0613

DCS - Dew-Point Calibration Systems DCS60, DCS80, DCS100



DCS80 with S8000RS

The DCS system is a complete rack-mounted calibration station capable of producing a flow of air (or nitrogen) at a pre-specified range of dew-point temperatures from a minimum of -100° C (-148° F) to a maximum of $+20^{\circ}$ C ($+68^{\circ}$ F).

When ordering this system, simply specify the required operating range, and Michell Instruments will determine the most economical way to construct your calibration system.

Each DCS comprises the following components:

Air Compressor

An oil-free laboratory mini compressor, used to generate clean compressed air to feed the air dryer system. The compressor can be housed within the calibration rack system (< 72 dbA noise level) or in a separate room, with an air feed to the DCS system.

Pressure Swing Dryer

The dryer provides a source of dry or super-dry air required by the generator. The PSD2 Dryer is used with the DCS80 calibration systems, and provides a supply of dry air with a dew point of -80°C (-112°F) or less in continuous operation. The PSD4 supplied with the DCS100 system provides dry air of -100°Cdp (-148°Fdp) dew point or less. An appropriate dryer will be selected for the calibration system, based on the dew-point range requirements specified.

Generator

The dew-point generator produces, and allows adjustment of, the flow of humidity controlled calibration gas. A DCS60/80 system can be supplied with either a DG2 or DG4 generator.

Reference

The DG2 dew-point generator allows full manual, analog control of the generated dew point by means of metering valves on the front panel.

The DG4 dew-point generator provides automated control of the generated dew point by allowing the selection of the desired dew point either via push buttons on the front panel, or by remote control via RS232 communications. The pre-set dew points are chosen at the time of order.

The DCS100 is supplied with a Vapor Delivery System (VDS) generator, which can be controlled directly or programmed to cycle through a range of outputs by means of dedicated control software.

Reference Hygrometer

The Reference Hygrometer serves to provide a dependable measurement of the calibration gas produced by the dew-point generator, to allow comparison against instruments under test.

A Chilled Mirror hygrometer directly measures the temperature at which condensation forms, and provides inherently repeatable, reliable results every time. Meaning is best suited for use as a reference instrument.

To ensure traceability to higher standards, the reference will be supplied with either a national standards traceable, or a UKAS accredited calibration.

Highlights

- Complete dew-point calibration solution with optional compressor, dryer, dew-point generator, reference instrument and optional manifold
- Generated output responds quickly to a change of set point
- Stable humidity generation
- Simple operation through manual flow mixing or push-button switching of set points
- Remote control via RS232 comms (dependant on model)



DCS - Dew-Point Calibration Systems

DCS60

The DCS60 is supplied with an S8000 Integrale, which is air cooled and has the capability to measure to dew points of -60° C (-76° F).

DCS80

The DCS80 is supplied with an S8000 RS, which features an automatically controlled auxiliary cooling system, and has the capability to measure to dew points of $-90^{\circ}C$ (-130°F).

DCS100

The DCS100 is supplied with an S4000 TRS, which utilizes a manually controlled auxiliary cooling system, and has the capability to measure to dew points of -100°C (-148°F).



DCS100

Calibration Manifold

Michell Instruments' dedicated systems engineering team can design and build for you a calibration manifold to suit any type of dew-point sensor, or a combination of sensors from different manufacturers. Just tell us the sensor type and we'll do the rest.

Housing

The whole system is conveniently mounted in a 19" rack unit for ease of use. If using a high purity air or nitrogen supply, this may be chosen as a feed to the system instead of the integral compressor/dryer system. A Michell Instruments' technical sales representative can give advice on how to accommodate this variation.

Technical Specifications

	DCS60	DCS80	DCS100
Range	-60 to +20°Cdp (-76 to +68°Fdp)	-80 to +20°Cdp (-112 to +68°Fdp)	-100 to +20°Cdp (-148 to +68°Fdp)
Air dryer	PSD2 Dryer	PSD2 Dryer	PSD4 Super Dryer
Generator method	DG2 with manual flow metering DG4 with solenoid controlled needle valves	DG2 with manual flow metering DG4 with solenoid controlled needle valves	VDS system with mass flow controllers
Reference hygrometer	S8000 Integrale Chilled Mirror Hygrometer	S8000 RS Chilled Mirror Hygrometer	S4000 TRS Chilled Mirror Hygrometer
Calibration flow rate	2 to 5 Nl/min (4.2 to 10.6 scfh)	2 to 5 Nl/min (4.2 to 10.6 scfh)	10 Nl/min (21.2 scfh)
Best system uncertainty	$\pm 0.2^{\circ}C (\pm 0.36^{\circ}F)$ dew point (k = 2) @ $\pm 20^{\circ}Cdp (\pm 68^{\circ}Fdp)$		
Set point precision	$\pm 0.5^{\circ}$ C ($\pm 0.9^{\circ}$ F) dew point		
Carrier gas	Oil-free compressed air (compressor supplied)		
Operating temperature	+15 to +30°C (+59 to +86°F)		
Traceability	Directly to NPL and NIST through Reference Hygrometer		
Power	220 to 240 V AC or 100 to 130 V DC, 50/60 Hz		
Housing	Wheeled 19" rack system, 1.9 m (74.8") high		
Weight	98kg (216lbs) (approx)	125kg (231lbs) (approx)	Varies

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DCS_97162_V3_UK_0315



Integrated Calibration Systems RH Calibration

HygroCal100 Humidity Validator



The HygroCal100 provides a stable test chamber to quickly evaluate the performance of relative humidity sensors across a wide range of 5 to 95% relative humidity. The intuitive design allows the probes under test to be fully integrated with the chamber and user interface (UI), so up to 7 probes with a variety of diameters and output signals can be powered, monitored and logged simultaneously by one self-contained unit.

A 4.3" LCD touch-screen runs a powerful UI, which displays all measured values from the reference and probes under test, along with a graphical trend indication of chamber stability. It is also capable of automating complete validation procedures with ease, and providing a complete logged output in csv format straight to your USB memory device, to minimize the time you spend taking readings.

Chamber Integrity

The HygroCal100 has a test chamber milled from a solid piece of Acetal, with minimal sealing points, ensuring the integrity required to maintain <5% RH from laboratory ambient temperatures, and $\pm 0.5\%$ RH uniformity across the chamber.

Portability

The HygroCal100 is fitted with a high capacity battery pack, which can power the generator and 7 sensors under test for up to 8 hours. The unit can also run from mains power while charging the battery.

A hard carry case is supplied with the unit, which has space for the HygroCal100 itself, in addition to the battery charger, spare water and desiccant.

Integrate Your Own Reference

The HygroCal interface allows you to assign any hygrometer with an analog output as your reference device, giving you the flexibility to incorporate your traceable reference in your validation routine.



Automated Validation

HS

The HygroCal100's advanced UI allows you to define your own calibration procedure, point-by-point, assigning times to each condition to allow your probes under test to stabilize. The system always waits until the conditions in the chamber are completely stable before beginning the check.

Correct Chamber Control To Your Own Reference

To ensure continual long term stability of the chamber, the in-built calibration correction system can compare the readings of your traceable reference to a range of pre-set generated conditions – making adjustments to the control sensor to ensure that your set point always matches your own reference.

Highlights


- Truly portable at 3.2kg, and completely selfcontained
- Intuitive UI makes automating probe verification simple
- Integral battery pack means validation can be done without access to services
- Validate 7 probes simultaneously
- Automated validation procedures for complete hands-off probe verification
- Internal calibration correction cycle ensures continued confidence
- Optional chilled mirror reference hygrometer, allowing use as a calibrator
- Download logged verification data direct to USB memory


HygroCal100

Technical Specifications

Chamber			
Generation range	5 to 95% RH		
RH stability	±0.5%		
RH uniformity	±0.5%		
Stabilization time	Typically <5 min for full stability from step changes of 10% RH		
Control Probe			
RH accuracy	±0.8%		
Temperature accuracy	±0.2°C (±0.36°C)		
Long term stability	±1% per year		
Electrical Specifications			
User interface	4.3" color LCD with touchscreen		
Interface with probes	24 V excitation voltage, accepts signals: 0–20 mA, 4–20 mA, 0–1 V, 0–5 V, 0–10 V		
Measurement units	%RH, temperature in °C, °F		
Displayed resolution	0.1		
Data logging	2Gb internal memory available for log files; or 10.6yrs storage at 5s intervals		
Battery	1500 mAh		
Power supply	24 V DC (100 to 240 V AC, 50/60 Hz adaptor included)		
Mechanical Specifications			
Probe ports	8 - port adaptors to accomodate probes of diameters: 12mm, 13.5mm, 14mm, 15mm, 18.5mm, 19mm, 24mm, 25mm		
Chamber volume	Approx 1050cm ³		
Maximum probe insertion depth	60mm (2.4")		
Desiccant reservoir capacity	25cm ³ (1.5 In ³)		
Saturator reservoir capacity	25ml		
Environmental conditions	+5 to +40°C (+41 to +104°F)		
Dimensions	100 x 250 x 300mm (3.9 x 9.8 x 11.8") (h x w x d)		
Weight	3.2kg (7lb)		

Dimensions





Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: HygroCal100_97502_V1_UK_Datasheet_1015

. .

.......

S904 Humidity Calibrator





The S904 is a completely stand-alone and transportable calibrator for humidity sensors, requiring no external services other than mains power. The calibration chamber features 5 interchangeable ports to accommodate virtually any brand, type or model of sensor. This calibrator is ideal for companies or organizations looking to calibrate large numbers of probes in a laboratory or field setting.

The environment within the insulated calibration chamber is temperature controlled using a 4-zone fanassisted Peltier arrangement for maximum stability, and minimum temperature gradient. The humidity of the circulating air is precisely regulated using a closed-loop control system that functions by proportionally mixing flows of dry and saturated air.

Two highly visible LED panels on the front of the S904 display the current humidity and temperature within the calibration chamber. The response time to a humidity or temperature step change is typically less than 10 minutes, so a simple 3-point calibration can be carried out in under an hour.

An optional integrated digital interface is available for the S904. This allows the humidity and temperature set points of the chamber to be controlled with the supplied PC application software, enabling the operator to create completely automated calibration profiles for unattended laboratory operation. The software also gives the ability to monitor, chart and log data from the connected probes and calibration reference on a PC for later analysis. Alternatively, the set points can be controlled manually with the front panel controls - making the S904 ideal for field calibrations where a PC is not available. The S904 is easy to maintain. The desiccant changes color to indicate when it needs to be recharged and this is visible through a clear window on the front of the unit. Recharging the desiccant is simply a matter of heating it in a conventional oven at $+150^{\circ}C$ ($+302^{\circ}F$) for 3 hours. The water reservoir at the front of the unit shows the current saturator fill level, and makes it easy to top-up with distilled water when required.

Highlights

- Simple operation and maintenance
- Excellent chamber stability and uniformity
- Manual control or optional straightforward automated set point programming
- Optional in-built data-logging for reference probe and probes under calibration




S904


Technical Specifications

Humidity	
Generation range	10–90% RH
Accuracy control element	≤±1% RH (10–70% RH) ≤±1.5% RH (70–90% RH)
Stability	±0.2% RH (20-80% RH)
Temperature	
Generated range	+10 to +50°C (+50 to +122°F) (lowest T set point = 10°C (18°F) below ambient)
Accuracy	±0.1°C (±0.2°F)
Stability	±0.1°C (±0.2°F)
Chamber	
Ramp rate from +20 to +40°C (+68 to +104°F) +40 to +20°C (+104 to +68°F)	1.5°C / minute (2.7°F / minute) 0.7°C / minute (1.2°F / minute)
Control element	Removable relative humidity sensor
General	
Probe ports	up to 5 – sensor body diameters 5 to 25mm (0.2 to 0.98") accommodated by port adapters
Chamber volume	2000cm ³ (122.1in ³)
Chamber dimensions	105 x 105 x 160mm (4.13 x 4.13 x 6.3") (h x w x d)
Instrument dimensions	290 x 520 x 420mm (11.4 x 20.5 x 16.5") (h x w x d)
Set point resolution	0.1 for humidity and temperature
Displays	3 digit LED, 10mm (0.39") characters
Supply	85 to 264 V AC, 47/63 Hz, 150 VA
Weight	30kg (66lbs)

Dimensions







Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: \$904_97200_V3.1_UK_0713 . . .

.



OptiCal Humidity Calibrator





The OptiCal is a premium calibration solution for humidity sensors. The stand-alone and transportable calibrator requires no external services other than mains power, and features an integrated chilled mirror reference instrument to enable the operator to perform calibrations that are traceable to national standards.

The calibration chamber features 5 interchangeable ports to accommodate virtually any brand, type or model of sensor. The environment within the insulated calibration chamber is temperature controlled using a 4-zone fanassisted Peltier arrangement for maximum stability, and minimum temperature gradient. The humidity of the circulating air is precisely regulated using a closed-loop control system that functions by proportionally mixing flows of dry and saturated air.

A bright and clear VFD (vacuum fluorescent display) displays the parameters measured by the reference instrument in various relative and absolute humidity units, alongside the temperature within the chamber.

The humidity and temperature set-points can be controlled either manually or automatically as part of a calibration program. Manual control is achieved by the switches on the front panel and response time to a humidity or temperature step change is typically quicker than 10 minutes. The supplied application software allows calibration programs to be created, enabling automatic time-based control of temperature and humidity set points. The software also allows the user to monitor, chart and log calibration reference data on a PC for later analysis. The OptiCal is supplied with an integrated Optidew chilled mirror reference instrument with traceable calibration to national standards, which provides measurement integrity and traceability for the sensors being calibrated.

The desiccant changes color to indicate when it needs to be recharged, and is visible through a clear window on the front of the unit. Recharging the desiccant is simply a matter of heating it in a conventional oven at +150°C (+302°F) for 3 hours. The water reservoir at the front of the unit shows the current saturator fill level, and makes it easy to top-up with distilled water when required. No other maintenance is necessary, apart from periodic calibration of the chilled mirror reference.

Highlights

- Simple operation and maintenance
- Excellent chamber stability and uniformity
- Manual control or optional straightforward automated set point programming
- Generate 10 to 90% RH over +10 to +50°C (+50 to +122°F) temperature
- Built in precision chilled mirror reference instrument
- Transportable to allow on-site calibrations




OptiCal


Technical Specifications

Humidity		
Generated range	10 - 90% RH	
Control element accuracy	≤ ±1% RH (10-70% RH) ≤ ±1.5% RH (70-90% RH)	
Stability	±0.2% RH (20-80% RH)	
Temperature		
Generated range	+10 to +50°C (+50 to +122°F) (lowest T set point = 10° C (18° F) below ambient)	
Accuracy	±0.1°C (±0.18°F)	
Stability	±0.1°C (±0.18°F)	
Chamber		
Ramp rate from +20 to +40°C (+68 to +104°F) +40 to +20°C (+104 to +68°F)	1.5°C / minute (2.7°F / minute) 0.7°C / minute (1.2°F / minute)	
Control element	Removable relative humidity sensor	
Reference		
Accuracy Dew Point Temperature	()	
Measurement units Dew Point Temperature		
Outputs Analog Accuracy Digital Alarm	output ±0.2°C (±3.6°F) 500 Ω maximum load resistance	
General		
Probe ports	Up to 5 - sensor body diameters 5 to 25mm (0.2 to 0.98") accommodated by port adapters	
Chamber volume	2000cm ³ (112.1in ³)	
Chamber dimensions	105 x 105 x 160mm (4.13 x 4.13 x 6.3") (w x h x d)	
Instrument dimensions	290 x 520 x 420mm (11.4 x 20.5 x 16.5") (h x w x d)	
Set-point resolution	0.1 for humidity and temperature	
Displays	2 line Vacuum Fluorescent Display	
Supply	85 to 264 V AC, 47/63 Hz, 150 VA	
Weight	20kg (44lbs)	

Dimensions



Chamber Dimensions



Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: OptiCal_97161_V3_UK_0613

.



HG10 Humidity Calibrator



The Michell HG10 Humidity Calibration System is a highly flexible computer-controlled automatic calibration system for humidity sensors. The HG10 is capable of repeatable generation of temperature and relative humidity set points over the range 1 to 95% RH (-50 to $+50^{\circ}$ Cdp (-58 to $+122^{\circ}$ Fdp)) at temperatures of +20 to $+50^{\circ}$ C (+68 to $+122^{\circ}$ F) with excellent stability. The supplied chilled mirror reference instrument provides traceability directly to national standards, and makes the system suitable for use in high-level calibration laboratories.

The HG10 comprises three main components, the humidity generator, test chamber and reference hygrometer.

Humidity Generator

The humidity generator used in the HG10 is based on the volumetric mixing of dry and wet gases, giving the fastest response when changing between set points in comparison to other dew-point generation technologies such as two-temperature, two-pressure or the combination of two-temperature and two-pressure. The mixing is automated using high-precision mass flow controllers to accurately control the ratio of wet to dry air, generating the required relative humidity.

A dry gas source is fed to the generator from a pressure swing dryer, and split into two streams. One stream is bubbled through liquid water via a sintered glass nozzle ensuring it is completely saturated with water vapor, while the other stream remains dry. The two gas streams are then mixed at atmospheric pressure to generate the target humidity level. The entire enclosure is insulated and temperature controlled ensuring the saturation, and therefore the output is always consistent. The generated sample gas is passed directly to the hygrometers under test using a heated sample line. Three clear digital displays on the front panel of the generator indicate the generator temperature, heat traced sample line temperature and relative humidity set point.

Generator

Reference

Test Chamber

Air Source

The standard HG10 chamber has internal dimensions of 550 x 550 x 320mm (21.6 x 21.6 x 12.6"), (h x w x d) and can be controlled and operated at temperatures from -10 to +50°C (+14 to +122°F). Alternative test-chambers are available in a range of different sizes and configurations. Please contact a Michell Instruments' representative for further details.

Reference Hygrometer

Drye

No calibration has validity unless it provides traceability to a recognized national standard. For this reason, the HG10 includes an S4000 Climatic Precision Chilled Mirror Hygrometer with a remote climatic sensor for precise monitoring of the generated humidity. The S4000 Climatic is calibrated in our UKAS laboratory, providing direct traceability to the UK national standard held by the National Physical Laboratory. Michell Instruments also maintains a traceable path directly to the NIST Humidity Standard in Washington, USA.

Automated Operation

The supplied PC software allows the creation of automatic calibration programs, for evaluating the performance of humidity sensors over a range of operating conditions. The measured values from the chilled mirror reference are used in a closed control loop to enable repeatable set point generation, time and time again.

Highlights

- No other single system generates as wide a range of wet to dry dew points
- High accuracy ±0.1°C (±0.18°F) fundamental reference
- User-configurable temperature and humidity profiling allows calibration cycles to be run without constant supervision
- Very fast changes between generated relative humidity points



HG10

Technical Specifications

HG10	
General	
Enclosure	19" Rack System, H=2.1m (6.8')
Power supply	100-115 V or 220 to 240 V 50/60Hz
Pressure Swing Dry	/er
Gas output Flow Pressure Moisture content	7 NI/min (14.8 scfh) 0.68 barg (10 psig) <1ppm _v (<-75°Cdp (<-103°Fdp))
Required gas supply Flow Pressure Moisture content	10 NI/min (21.2 scfh) 5 to 7 barg (70 to 100 psig) Oil and liquid water-free
Туре	Twin column desiccant, pressure swing
Desiccant	4 Ångström Molecular sieve bead (4-8 mesh)
Timer	Motorized cam
Operating temperature	+5 to +35°C (+41 to +95°F)
Generator	
Generation range Humidity Temperature	1 to 95% RH (-50 to +50°Cdp (-58 to +122°Fdp)) Dependant on temperature chamber
•	
Generated gas output	Air 2 NI/min (4.2 scfh) @ 0.5 barg (7 psig) via heat traced line
Dual stage MFC mixing	Dual mass flow controllers
Power consumption	550 V A maximum
Operating temperature	+5 to +40°C (+41 to -104°F;) 10 to 90% RH
Enclosure	19" Rack System, H= 2.1m (6.8")
Control system	Closed loop feedback
Reference Instrum	ent
Performance	
Measurement technology	Chilled Mirror
Measurement range	-80 to +85°Cdp (-112 to +185°Fdp)
Measurement accuracy	±0.1°Cdp (±0.18°Fdp) ±0.1°C (±0.18°F) temperature
Repeatability	Better than 0.1°C (±0.18°F)
Resolution	0.01 (0.1 for % RH)
Dew-Point Sensor	
Mirror	Gold plated copper

Remote PRT		
Temperature measurement	4 wire Pt100, 1/10 DIN class B	
Monitor		
Resolution	0.01°C (0.018°F)	
Dual optics detection	Wide band red LED with dual photo sensors, all system insulated	
Outputs Analog Digital Logic	2 channels, 10 mV/°Cdp, 4-20mA RS232 Data hold, ABC Logic status, optics alarm	
Operating temperature	0 to + 40°C (+32 to +104°F)	

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: HG10_97158_V2_UK_0613

4 wire Pt100, 1/10 DIN class B

0.1 to 0.7 NI/min (0 to 1.5 scfh) (recommended)

0 to 1 NI/min (0 to 2.1 scfh)

Atmospheric

Remote

Temperature

measurement

Configuration

Sample flow rate

Integrated flowmeter Sensor pressure





Order Codes Content


PSD2 & PSD4	52
DG2 and DG3	53
DG4	53
VDS3	53
Optidew Vision	54
S8000 Integrale	56
S8000 Remote	57
S8000 RS	58
\$4000	59
HG1	60
DCS60 Dew-Point Calibration System	61
DCS80 Dew-Point Calibration System	62
DCS100 Dew-Point Calibration System	63
HygroCal100	64
S904	65
OptiCal	66
HG10	67

PSD2 & PSD4 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}

Ordering Example: PSD-4 + 240

PSD4 ultra high performance dryer, 220 to 260 V AC



CMP - Compressor and Reservoir for PSD2/4

Item	Product / Description
CMP-10-240	Mini compressor to feed PSD2
CMP-25-240	Compressor and reservoir to feed PSD4

Accessories and Spare Parts

Item	Product / Description
PSD-4-FO	Outlet Millipore wafergard inline sealed particulate filter 0.003µm
PSD-4-FV	Vent particulate filter element 0.1µm

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: PSD2 and PSD4 Order Codes_97160_V2.1_UK_0415



.


DG2 and DG3

Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

Ordering Example: DG-3 + 240 + S06

DG3, 1 stage mixing manual -40 to +20°Cdp (-40 to +68°Fdp), 220 to 260 V AC, with 6 additional generation set points




DG4 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

Ordering Example: DG-4SP + 240 + S06

DG4 Solenoid operation, 220 to 260 V AC, with 6 additional generation set points



VDS3 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A}

Ordering Example: VDS-3

VDS: Computer controlled stand-alone dew-point generator with range -100 to +20°Cdp (-148 to +68°Fdp)

		VDS-3
Base Model		
VDS: Computer controlled stand-alone dew-point generator Base unit - Range -100 to +20°Cdp (-148 to +68°Fdp)	VDS-3	

Custom-built calibration systems are available covering the range from -100°Cdp (-148°Fdp) (10 ppb_v) up to +85°Cdp (+185°Fdp). Please discuss your requirements with Michell Instruments' technical sales department.

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: Dew Point Generators Order Codes_97334_V3_UK_0616



Optidew Vision Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature D} + {Feature D} + {Feature F}

Ordering Example: OPV + HT-SC02 + 02-ACE-SS + H + 232 + CM-STD

Optidew Vision with 2m (6.6') high temperature cable assemblies for dew point & temperature, 2 stage sensor Acetal housing + stainless steel stud mirror, high pressure (up to 3625 psig / 250 barg), RS232 output & standard traceable in-house calibration

02-ACE-SS

H 232 CM-STD

	OPV HT:	5C02
Base Model {Feature A}		
Base unit: Dew-Point Hygrometer	OPV	
Cable {Feature B}		
No cable	SC0	
2m (6.56') cable assemblies (for dp & t) – max temp: +70°C	SC02	
5m (16.4') cable assemblies (for dp & t) – max temp: +70°C	SC05	
10m (32.8') cable assemblies (for dp & t) – mattemp: +70°C	x SC10	
2m (6.56') high temp cable assemblies (for dp t) – max temp: +180°C	& HT-SC02	
5m (16.4') high temp cable assemblies (for dp t) – max temp: +180°C	& HT-SC05	
10m (32.8') high temp cable assemblies (for dp & t) – max temp: +180°C	HT-SC10	
Other cable lengths available on special request meter above 2m	t, price per	
	-	_
Sensor {Feature C}		
1 stage sensor Acetal + Au coated Cu mirror	01-ACE-STD	
2 stage sensor Acetal + Au coated Cu mirror	02-ACE-STD	
2 stage sensor Acetal + Au stud mirror	02-ACE-AUS	
2 stage sensor Acetal + SS stud mirror	02-ACE-SS	

02-ACE-PLT

02-PEEK-STD

02-PEEK-AUS

02-PEEK-SS

02-PEEK-PLT

02-SS-STD

02-SS-AUS

02-SS-SS

02-SS-PLT

02-AL-STD

02-AL-AUS

02-AL-SS

02-AL-PLT CLIMATIC

0	0.0	
	Calibration {Feature F}	
	Standard traceable in-house calibration	CM-STD
	High accuracy traceable calibration to $\pm 0.15^{\circ}C (\pm 0.27^{\circ}F)$	CM-ACC
	5-pt UKAS dew-point calibration (specify points required on order)	CM-DPUKAS
	Additional UKAS dew-point calibration point	CM-DPAP01
	5-pt UKAS RH calibration at one temp (specify points required on order)	CM-RHUKAS
	Additional UKAS RH calibration point	CM-RHAP01
	Additional five UKAS RH points at alt temp	CM-RHAT
	Digital {Feature E}	
	RS232	232
	RS485	485
	Pressure {Feature D}	
	Low pressure (up to 290 psig / 20 barg)	L
	High pressure (up to 3625 psig / 250 barg)	Н



2 stage sensor Acetal + Pt stud mirror

2 stage sensor PEEK + Au stud mirror

2 stage sensor PEEK + SS stud mirror

2 stage sensor PEEK + Pt stud mirror

2 stage sensor SS + Au stud mirror

2 stage sensor SS + SS stud mirror

2 stage sensor SS + Pt stud mirror

2 stage sensor AL + Au stud mirror

2 stage sensor AL + SS stud mirror

2 stage sensor AL + Pt stud mirror

2 stage aluminum climatic sensor

2 stage sensor SS + Au coated Cu mirror

2 stage sensor AL + Au coated Cu mirror

2 stage sensor PEEK + Au coated Cu mirror

Optidew Vision Order Codes

Accessories and Spare Parts

Item	Product / Description
Sensor Guards	
OPT-SSG	Sintered SS guard (for particulate contamination 10-12µm)
OPT-HSG	HDPE sintered guard (for particulate and liquid protection 10µm)
OPT-SSB	Sensor sampling block - SS with 1/8" NPT in/out threaded gas ports
External Connections	
OPV-DPSC-02	2m (6.56') sensor cable with connectors (dew point only) — Max temp: +70°C
OPV-DPSC-05	5m (16.4') sensor cable with connectors (dew point only) — Max temp: +70°C
OPV-DPSC-10	10m (32.8') sensor cable with connectors (dew point only) — Max temp: +70°C
OPV-DPHTSC-02	2m (6.56') high temperature sensor cable (with connectors, dew point only) — Max temp: +180°C
OPV-DPHTSC-05	5m (16.4') high temperature sensor cable (with connectors, dew point only) — Max temp: +180°C
OPV-DPHTSC-10	10m (32.8') high temperature sensor cable (with connectors, dew point only) — Max temp: +180°C
OPT-PRT-02	Remote PRT, 2m (6.56') cable with connector — Max temp: +70°C
OPT-PRT-05	Remote PRT, 5m (16.4') cable with connector — Max temp: +70°C
OPT-PRT-10	Remote PRT, 10m (32.8') cable with connector — Max temp: +70°C
OPT-PRTHT-02	Remote PRT, 2m (6.56') with high temperature cable and connector — Max temp: +250°C
OPT-PRTHT-05	Remote PRT, 5m (16.4') with high temperature cable and connector — Max temp: +250°C
OPT-PRTHT-10	Remote PRT, 10m (32.8') with high temperature cable and connector — Max temp: +250°C
Other cable lengths available on speci	ial request, price per meter — above 2 meters
Miscellaneous	
OPT-ACH-110 OPT-ACH-220	Air cooled heatsink, heat sink and cooling fan (specify 110 or 220V) (includes sensor sampling block)
OPT-LCB	Liquid cooled block w/gas ports & coolant channel (requires ext coolant supply)
OPT-SLK	Sensor lock nut kit (to mount the dew-point sensor to a panel or bulkhead)
OPV-PMK	Panel mounting kit for 19" rack
OPV-TCS	Heavy duty transport case
CM-CLN-KIT	Cleaning materials (required for periodic maintenance of chilled mirror dew-point hygrometer sensors - fluids not included)

Services

Item	Product / Description
CM-TC	Traceable calibration (as supplied as standard with new instrument)
OPT-ACC	High accuracy calibration to $\pm 0.15^{\circ}$ Cdp ($\pm 0.27^{\circ}$ F) (not available with SS sensor)
READINGS	Readings before calibration (calibration data recorded before adjustment)
CM-DPUKAS	5-pt UKAS dew-point calibration (specify points required on order)
CM-DPAP01	Additional calibration points for UKAS calibration
CM-RHUKAS	5-pt UKAS RH calibration at one temp (specify points required on order)
CM-RHAP01	Additional calibration points for % RH (at the same temperature)
CM-RHAT	UKAS % RH calibration of 5 points (at an additional temperature, please contact MIL before ordering)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: Optidew Vision Order Codes_97144_V4_UK_0616



S8000 Integrale

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C} + {Feature D} + {Feature B} + {Feature B} + {Feature G}

Ordering Example: S8K-I-HP + B2 + C0 + D1 + E0 + F1 + G1

S8000 Integrale Chilled Mirror Hygrometer, high pressure version (20 barg max), USB and Ethernet communications, no pump, internal pressure sensor, no external PRT connections, 6mm Swagelok® tube fittings, standard traceable in-house calibration

ī				1	<u> </u>		11	11		
	S8K-I-HP	B2	C0	D:	1	E0	F1	L	G1	
Base Model {Feature A}	•								Calibration {Feature G}	
S8000 Integrale Chilled Mirror Hygrometer low pressure version (1 barg max)	S8K-I-LF								Standard traceable in-house calibration	G1
S8000 Integrale Chilled Mirror Hygrometer	S8K-I-H								5-pt UKAS dew-point calibration (specify points required on order)	G2
high pressure version (20 barg max)									Additional UKAS calibration point	G3
Communications {Feature B}		μ					l		Fittings {Feature F}	
USB only	B1								6mm Swagelok [®] tube fittings	F1
USB + Ethernet	B2								1/4" Swagelok [®] tube fittings	F2
USB + RS232 B3								i		
USB + RS485 B4									External PRT Connections {Feature E}	
									No external PRT connections	E0
Sample Pump {Feature C}		_							External connections for direct PRT measurement	E1
No pump	C0									
Integral sample pump and flow control valve with 6mm	C1								Pressure Sensor {Feature D}	D0
Integral sample pump and flow control valve with 1/4"	C2								No internal pressure sensor Internal pressure sensor	D0 D1

Accessories and Spare Parts

Item	Product / Description
S8K-PRT	Remote PRT, 2m cable with connector
S8K-RS-MCI	Mirror viewing microscope
CM-CLN-KIT	Cleaning materials (required for periodic maintenance of Chilled Mirror Hygrometer sensors, fluids not included)
S8K-RS232	RS232 communications module (installation by Michell engineer only)
S8K-RS485	RS485 communications module (installation by Michell engineer only)
S8K-LAN	Ethernet communications module (installation by Michell engineer only)
S8K-PUMP	Integral sample pump module (installation by Michell engineer only)

Services

Order Codes	Product / Description
CM-TC	Traceable calibration (as supplied as standard with new instrument)
READINGS	Readings before calibration (calibration data recorded before adjustment)
CM-DPKAS	5-pt UKAS dew-point calibration (specify points required on order)
CM-DPAP01	Additional calibration points for UKAS calibration
CM-RHUKAS	5-pt UKAS RH calibration at one temp (specify points required on order)
CM-RHAP01	Additional calibration points for %RH (at the same temperature)
CM-RHAT	UKAS %RH calibration of 5 points at an additional temperature (please contact MIL before ordering)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version.

Issue No: S8000 Integrale MKII_97509_V1.1_UK_Order Codes_0316



S8000 Remote Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C} + {Feature D} + {Feature E}

Ordering Example: S8K-REM + B1 + C1 + D1 + E1

S8000 Remote with 2m (6.6') cable assemblies for sensor and external PRT with standard traceable in-house calibration with acetal sensor + Au coated Cu mirror, low pressure (up to 300 psig/20 barg) version

	Г	S8K-I	DEM	B1	C1	D1	E1		
		201-1		1					
								Pressure {Feature E}	
Base Model {Feature A}		ł						 Low pressure (up to 300 psig/20 barg)	E1
S8000 Remote Dew-Point Hygrometer (with LCD	S8K-RI	EM						High pressure (up to 3600 psig/250 barg)	E2
display and in-built data logging of measurement)						L		Sensor {Feature D}	
								Acetal + Au coated Cu mirror	D1
Cable {Feature B}								Acetal + Au stud mirror	D2
2m (6.6') cable assemblies for sensor and external PRT	B1							AI + Au coated Cu mirror	D3
								AI + Au stud mirror	D4
5m (16.4') cable assemblies for sensor and external PRT	B2							Aluminum climatic sensor	D5
10m (32.8') cable assemblies for sensor and external PRT	B3							Calibration {Feature C}	
								Standard traceable in-house calibration	C1
								5-pt UKAS dew-point calibration (specify points required on order)	C2
								Additional UKAS dew-point calibration point	C3
								%RH calibration - up to & including 5 pt (@ one temp with UKAS Cert)	C4

Accessories and Spare Parts

Item	Product / Description
S8K-REM-PS02	External pressure sensor with 2m (6.6') cable
S8K-REM-PS05	External pressure sensor with 5m (16.4') cable
S8K-REM-PS10	External pressure sensor with 10m (32.8') cable
S8K-PRT	Remote PRT, 2m (6.6') cable with connector
S8K-PKI	Panel mounting kit for 19" rack
S8K-REM-TCI	Transport case
OPT-SSB	Sensor sampling block
OPT-SLK	Sensor lock nut (to mount sensor to panel or bulkhead)
OPT-HSG	HDPE sintered guard (for particulate and liquid protection 10µm)
S8K-REM-TSG	S8000 Remote guard for S904
OPT-SSG	Sintered SS guard (for particulate contamination 10-12µm)
CM-CLN-KIT	Cleaning materials (required for periodic maintenance of chilled mirror dew-point hygrometer sensors - fluids not included)

Services

Order Codes	Product / Description
CM-TC	Traceable calibration (as supplied as standard with new instrument)
READINGS	Readings before calibration (calibration data recorded before adjustment)
CM-DPUKAS	5-pt UKAS dew-point calibration (specify points required on order)
CM-DPAP01	Additional calibration points for UKAS calibration
CM-RHUKAS	5-pt UKAS RH calibration at one temp (specify points required on order)
CM-RHAP01	Additional calibration points for %RH (at the same temperature)
CM-RHAT	UKAS %RH calibration of 5 points (at an additional temperature, please contact MIL before ordering)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S8000 Remote Order Codes_97307_V2_UK_0316




S8000 RS Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C} + {Feature D} + {Feature E}

Ordering Example: S8K-RS + B2 + C1 + D2 + E2

S8000 RS, -90 to +20°Cdp (-130 to +68°Fdp) range, USB, internal pressure transducer and 5-pt UKAS dew-point calibration



Accessories and Spare Parts

Item	Product / Description
S8K-RS-PKI	19" rack mounting kit
S8K-RS-PRT	Remote PRT, 2m (6.6') cable with connector
S8K-RS-MCI	Microscope
S8K-RS-TCI	Transport case
CM-CLN-KIT	Cleaning materials (required for periodic maintenance of chilled mirror dew-point hygrometer sensors - fluids not included)
GEN-VCRW14GR	1/4" VCR Washer with Gasket Retainer
GEN-14VCR6	1/4" VCR Female to 6mm Swagelok Tube
GEN-14VCR14	1/4" VCR Female to 1/4" Swagelok Tube

Services

Order Codes	Product / Description
CM-TC	Traceable calibration (as supplied as standard with new instrument)
READINGS	Readings before calibration (calibration data recorded before adjustment)
CM-DPUKAS	5-pt UKAS dew-point calibration (specify points required on order)
CM-DPAP01	Additional calibration points for UKAS calibration
CM-RHUKAS	5-pt UKAS RH calibration at one temp (specify points required on order)
CM-RHAP01	Additional calibration points for %RH (at the same temperature)
CM-RHAT	UKAS %RH calibration of 5 points (at an additional temperature, please contact MIL before ordering)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S8000 RS Order Codes_97316_V4.1_UK_0616




S4000 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

Ordering Example: S4K + TRS + 232

S4000 TRS with dual stage refrigerant booster, RS232 communications



Accessories and Spare Parts

Item	Product / Description
S4K-MC	Microscope
S4K-PRT	Remote PRT, 2m (6.6') cable with connector
CM-CLN-KIT	Cleaning materials (required for periodic maintenance of chilled mirror dew-point hygrometer sensors - fluids not included)
GEN-VCRW14GR	1/4" VCR Washer with Gasket Retainer
GEN-14VCR6	1/4" VCR Female to 6mm Swagelok Tube
GEN-14VCR14	1/4" VCR Female to 1/4" Swagelok Tube

Services

Order Codes	Product / Description
CM-DPUKAS	5-pt UKAS dew-point calibration (specify points required on order)
CM-DPAP01	Additional calibration points for UKAS calibration
CM-RHUKAS	5-pt UKAS RH calibration at one temp (specify points required on order)
CM-RHAP01	Additional calibration points for % RH (at the same temperature)
CM-RHAT	UKAS % RH calibration of 5 points (at an additional temperature, please contact MIL before ordering)
READINGS	Report on measurement accuracy before re-calibration

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S4000 TRS Order Codes_97146_V3_UK_0316

.




HG1 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

Ordering Example: HG1 + INT + 240

HG1 with in-built reference instrument (Optidew) for 220 to 260 V AC operation



Accessories and Spare Parts

Item	Product / Description
HG1-CC	Chamber cover for 8 probes (max) (dependant upon probe type)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: HG1 Order Codes_97158_V1.1_UK_0415

.



DCS60 Dew-Point Calibration System

Order Codes

To construct the order code, select the relevant features from the tables below, to create a string: {Dry Air Generaton} + {Dew-Point Generator} + {Dew-Point Hygrometer}

Ordering Example: PSD-2 + 240 + DG-4SP + 240 + S10 + S8K-I-LP + B2 + C0 + D0 + E0 + F1 + G2

PSD2 Pressure Swing Dryer, 220 to 260 V AC, DG4 Dew-Point Generator, 220 to 260 V AC, with 10 additional generation set points, S8000 Integrale Chilled Mirror Hygrometer low pressure version (1 barg max), USB + Ethernet communications, no pump, no internal pressure sensor, 6mm Swagelok Tube Fittings, 5-pt UKAS dewpoint calibration


Dry Air Generation - Pressure Swing Dryer

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}

		PSD-2	240		
Base Model {Feature A}				Power {Feature B}	
PSD2 high performance dryer	PSD-2			90 to 120 V AC	110
(Range < -80°Cdp (-112°Fdp))				220 to 260 V AC	240

Dew-Point Generator

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}



Dew-Point Hygrometer (with LCD display and in-built data logging of measurement

	S8K-I-LP	B2	C0	D0	E)	F1		G2	
Base Model {Feature A}	1							[Calibration {Feature G}	
S8000 Integrale Chilled Mirror Hygrometer	S8K-I-LP	,							Standard traceable in-house calibration	G1
low pressure version (1 barg max)									5-pt UKAS dew-point calibration	G2
Communications {Feature B}		μ							(specify points required on order)	
USB only	B1								Additional UKAS calibration point	G3
USB + Ethernet	B2								Fittings {Feature F}	
USB + RS232	B3								6mm Swagelok Tube Fittings	F1
USB + RS485	B4								1/4" Swagelok Tube Fittings	F2
Sample Pump {Feature C}								—[External PRT Connections {Feature E}	
No pump	C0								No external PRT connections	E0
Integral sample pump and flow control valve w/ 6mm	C1								External connections for direct PRT measurement	E1
Integral sample pump and fl ow control	C2			L				[Pressure Sensor {Feature D}	
valve w/ 1/4"									No internal pressure sensor	D0
Options									Internal pressure sensor	D1

Options

Item	Product / Description
Rack System	
DCS-RAK	Floor standing rack with instrument shelf (for positioning of instrument / sensor under test)
Compressor System	
CMP-10-240	Oil-free air mini compressor, 29 psig/2 barg, 10 Nl/min (for PSD-2)
CMP-SPC	Soundproof cabinet for compressor
Sensor Manifold	
DCS-MAN	Sensor manifold (Manufactured to suit the customer's sensors typically in anodized aluminum for RH probes or 316 SS for dew-point sensors, price available on request when sensors to be calibrated are fully defined)
Please note: Michell Instrume	nts adonts a continuous develonment program which sometimes

Please note: Michell Instruments adopts a continuous velopment progra necessitates specification changes without notice. Please contact us for latest version. Issue No: DCS60 Order Codes_97162_V3_UK_0316



DCS80 Dew-Point Calibration System

Order Codes

To construct the order code, select the relevant features from the tables below, to create a string: {Dry Air Generaton} + {Dew-Point Generator} + {Dew-Point Hygrometer}

Ordering Example: PSD-2 + 240 + DG-4SP + 240 + S10 + S8K-RS + B1 + C2 + D1 + E2 PSD2 Pressure Swing Dryer, 220 to 260 V AC, DG4 Dew-Point Generator, 220 to 260 V AC, with 10 additional generation set points, S8KRS Dew-Point Hygrometer, -80 to +20°Cdp (-112 to +68°Fdp), USB & Ethernet, 5-pt UKAS dew-point calibration

Dry Air Generation - Pressure Swing Dryer

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}

		PSD-2 240	
Base Model {Feature A}		Power {Feature B}	
PSD2 high performance dryer	PSD-2	90 to 120 V AC	110
(Range < -80°Cdp (-112°Fdp))		220 to 260 V AC	240

Dew-Point Generator

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

		DG-4SP	240	S10		
Type {Feature A}	-				Set Point {Feature C}	
DG2, 2 stage mixing manual, -75 to +20°Cdp (-103 to +68°Fdp)	DG-2				Total number of set points (maximum of 10 set points e.g. $S10 = 10$ points)	SXX
DG4, solenoid operation (controlled from front panel keypad or through RS232 comms. 3 set points (max 10) in addition to a full dry point,	DG-4SP					
set points to be specified at time of order, range -75 to +20°Cdp (-103 to +68°Fdp))					Power {Feature B}	
75 to +20 cap (105 to +00 + ap))					90 to 120 V AC	110
					220 to 260 V AC	240

Dew-Point Hygrometer (with LCD display and in-built data logging of measurement

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C} + {Feature D} + {Feature E}

			S8K-RS	B1	C1	D1	E2		
Base Model {Feature A}							Calib	ration {Feature E}	
S8000 RS, Dew-Point Hygrometer (with	S8K-RS						Stand	lard traceable in-house calibration	E1
LCD display and in-built data logging of measurement)								JKAS dew-point calibration ify points required on order)	E2
Range {Feature B}							Additi	ional UKAS dew-point calibration point	E3
-80 to +20°Cdp (-112 to +68°Fdp)	B1								
-90 to +20°Cdp (-130 to +68°Fdp)	B2						- Press	sure Sensor {Feature D}	
		-					No int	ternal pressure sensor	D1
Communications {Feature C}							Interr	nal pressure sensor (0-16 bara)	D2
USB only	C1								
USB and Ethernet	C2								

Options

Item	Product / Description
Rack System	
DCS-RAK	Floor standing rack with instrument shelf (for positioning of instrument / sensor under test)
Compressor System	
CMP-10-240	Oil-free air mini compressor, 29 psig/2 barg, 10 NI/min (for PSD-2)
CMP-SPC	Soundproof cabinet for compressor
Sensor Manifold	
DCS-MAN	Sensor manifold (Manufactured to suit the customer's sensors typically in anodized aluminum for RH probes or 316 SS for dew-point sensors, price available on request when sensors to be calibrated are fully defined)

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DCS80 Order Codes_97162_V3_UK_0316

.



DCS100 Dew-Point Calibration System

Order Codes

To construct the order code, select the relevant features from the tables below, to create a string: {Dry Air Generaton} + {Dew-Point Generator} + {Dew-Point Hygrometer}

Ordering Example: PSD-4-STD + 240 + VDS-3 + S4K-TRS + 232 + 240

PSD4 Pressure Swing Dryer, 220 to 260 V AC, VDS3 Dew-Point Generator, S4KTRS Dew-Point Hygrometer, RS232, 220 to 260 V AC

Dry Air Generation - Pressure Swing Dryer

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}

		PSD-4	240		
Base Model {Feature A}		<u>]</u>		Power {Feature B}	
Ultra high performance dryer (Range < -100°Cdp)	PSD-4-STD			90 to 120 V AC 220 to 260 V AC	110 240
Ultra high performance dryer with high pressure output (Range < -100°Cdp)	PSD-4-HPO			220 t0 200 V AC	240
Ultra high performance dryer with 90NI/min output (Range < -100°Cdp)	PSD-4-HFV				


Dew-Point Generator

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A}

Base Model {Feature A}		
VDS: Computer controlled stand-alone dew-point generator Base unit - Range -100 to +20°Cdp (-148 to +68°Fdp)	VDS-3	

Dew-Point Hygrometer

To construct the order code, select the relevant feature from the tables below, starting with the type, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}



Options

Item	Product / Description
Compressor System	
CMP-25-240	Compressor and reservoir to feed PSD-4 & DG
Pre-Dryer	
DCS-PRE	Domnick Hunter pre-dryer (to dry PSD4 air supply to -40°Cdp (-40°Fdp))
Sensor Manifold	
DCS-MAN	Sensor Manifold (Manufactured to suit the customer's sensors typically in anodized aluminum for RH probes or 316 SS for dew-point sensors, price available on request when sensors to be calibrated are fully defined)

Accessories and Spare Parts

Item	Product / Description
PSD-4-FO	Outlet Millipore wafergard inline sealed particulate filter 0.003µm
PSD-4-FV	Vent particulate filter element 0.1µm

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: DCS100 Order Codes_97162_V3_UK_0316

.



HygroCal100 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C} + {Feature D} + {Feature E} + {Feature F}

Ordering Example: HC100-B2+C1+D1+E1+F1+F1+F1+F6+F6+F6 HygroCal100 with internal battery, MDM25 calibration kit, Transport case, euro power supply, 4x 12mm port adaptors and 3x 19mm port adaptors

	HC100	B2	C1	D1	E	1	F1, F	1, F1, F	1, F6 ,F6, F6]	
										1	
Base Model {Feature A}								Port A	Adaptors {Featur	eF}	
Portable Humidity Validator + 7 probe input	HC100							Port ac	daptor 12mm (0.47	")	F1
connectors, 8 user specified port adapters, port adapter tool, syringe and desiccant.								Port ac	daptor 13.5mm (0.	53″)	F2
								Port ac	daptor 14mm (0.55	5")	F3
Calibration Kit {Feature B}								Port ac	daptor 15mm (0.59)")	F4
No additional calibration equipment	B1							Port ac	daptor 18.5mm (0.	73")	F5
Calibration kit 1 (HC100 including MDM25 hand-held	B2*							Port ac	daptor 19mm (0.75	5")	F6
hygrometer and probe with calibration								Port ac	daptor 24mm (0.94	ł")	F7
certificate and 7 user specified port adaptors)								Port ac	daptor 25mm (0.98	8")	F8
Calibration kit 2 (Optidew Vision Chilled Mirror Hygrometer,	B3**							Power	r Lead {Feature	E}	
Optidew port adaptor kit and 6 user specified port adaptors)								Europe	ean power supply		E1
								UK pov	wer supply		E2
*If option B2 is selected, only 7 port adaptors sl chosen	nould be							North	American power su	ipply	E3
**If option B3 is selected, only 6 port adaptors	should be							Austra	lian power supply		E4
chosen								T			
Internal Battery {Feature C}				L					port Case (Featu	-	50
No internal battery	C0								nsport case supplie		D0
Internal battery	C1							Hygro	oort case with foam Cal100 and accesso siccant and water		D1

Accessories and Spare Parts

Item	Product / Description
HC100-CHA	HC100 power supply adaptor
A000171	Spare 0.25kg desiccant
A000172	Spare 3kg desiccant
HC100-TC	Spare carry case
HC100-BOT	Bottles for spare desiccant and water storage
HC100-CMKIT	Optidew/S8000 Remote port adaptor kit
HC100-HS3CON	HygroSmart 3 cable connector
HC100-CON	Spare phoenix connector, screw terminal
HC100-HS3-S-R	Replacement Hygrosmart Sensor, prepared for the HC100
Port Adaptors (8 port a	adaptors can be specified free-of-charge with a new HygroCal100)
A000291	Port adaptor 12mm (0.47")
A000292	Port adaptor 13.5mm (0.53")
A000293	Port adaptor 14mm (0.55")
A000294	Port adaptor 15mm (0.59")
A000295	Port adaptor 18.5mm (0.73")
A000296	Port adaptor 19mm (0.75")
A000297	Port adaptor 24mm (0.94")
A000298	Port adaptor 25mm (0.98")

Michell Instruments adopts a continuous development programme which sometimes necessitates specification changes without notice. Issue no: HygroCal100_97502_V2_UK_Order Codes_0516



S904 Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B} + {Feature C}

Ordering Example: S904 + 263 + 13.5

Base unit, S904, Relative Humidity and Temperature Generator for Humidity and Temperature Calibrations with Port adapter 13.5mm (0.53"), door with 5 ports

	S904	263	13.5	
Type {Feature A}		1	Adaptor {Feature C}	
Base unit, S904, Relative Humidity and Temperature Generator for Humidity and Temperature Calibrations	S904		Port adapter 12mm (0.47")	12.0
Base unit - with RS232/USB interface (data-logging software	S904-D		Port adapter 13.5mm (0.53")	13.5
for PC - 6 channel data-logger)			Port adapter 14mm (0.55")	14.0
Door {Feature B}			Port adapter 15mm (0.59")	15.0
Door with 5 ports	263		Port adapter 18.5mm (0.73")	18.5
Door with clear window - no ports	266		Port adapter 19mm (0.75")	19.0
Door without ports	268		Port adapter 24mm (0.94")	24.0
Door kit for use with Optidew	269		Port adapter 25mm (0.98")	25.0
Door kit with 1x 30mm port	370			

Accessories and Spare Parts

Item	Product / Description
Doors and Door Ports	
A000266	Door with clear window - no ports
A000268	Door without ports
A000263	Door kit with 5 ports - please order adaptors separately
A000264	Door kit with 5 ports and 25 adapters (5 x ø19mm (0.75"), 4 x ø12mm (0.47"), ø13.5mm (0.53"), ø15mm (0.59"), ø18.5mm (0.73"), ø24mm (0.94") - and blind stops. Adapter tool included
A000269	Door kit for use with MI Optidew. (Optidew dew-point sensor port adapter, PRT port adapter and 4 x ø19mm (0.75") adapters - adapter tool included)
A000273	Polymer port adpt ø18.5mm (0.73") to ø3mm (0.19") (for Optidew probe)
A000290	Molded polymer port adpt & blind stop (to be modifi ed by customer) (M30x1)
A000290X	Polymer port adpt ø client specific & blind stop
A000291	Polymer port adpt for ø12mm (0.47") probe, blind stop (M30x1)
A000292	Polymer port adpt for ø13.5mm (0.53") probe, blind stop (M30x1)
A000293	Polymer port adpt for ø14mm (0.55") probe, blind stop (M30x1)
A000294	Polymer port adpt for ø15mm (0.59") probe, blind stop (M30x1)
A000295	Polymer port adpt for ø18.5mm (0.73") probe, blind stop (M30x1)
A000296	Polymer port adpt for ø19mm (0.75") probe, blind stop (M30x1)
A000297	Polymer port adpt for ø24mm (0.95") probe, blind stop (M30x1)
A000298	Polymer port adpt for ø25mm (0.98") probe, blind stop (M30x1)
A000277	Blind stop for Optidew adapter
A000278	Blind stop for PRT adapter
A000200	ø18.5mm (0.73") Blind stop
A000265	Tool for changing the port adapters
Miscellaneous	
OPT-V-01	Optidew Vision reference hygrometer with sensor
A000240	Drying module
A000242	Water bottle
A000171	0.25kg (0.55lbs) desiccant (orange)
A000172	3kg (6.6lbs) desiccant (orange)
HT961T00	Control sensor
OCAL-TC	Transport case for OptiCal and S904
S8K-REM-TSG	S8000 Remote guard for S904

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: S904 Order Codes_97200_V3_UK_0516






OptiCal Order Codes

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A}

Ordering Example: OPTICAL

OptiCal - Precision humidity calibration system with temperature control includes 5 port door and integrated chilled mirror reference hygrometer with 3 point UKAS RH calibration



Accessories and Spare Parts

Item	Product / Description
Doors and Door Ports	
A000266	Door with clear window - no ports
A000268	Door without ports
A000263	Door with 5 ports – please order adapters separately
A000264	Door kit with 5 ports and 25 adapters (5 x ø19mm (0.75"), 4 x ø12mm (0.47"), ø13.5mm (0.53"), ø15mm (0.59"), ø18.5mm (0.73"), ø24mm (0.94") - and blind stops. Adapter tool included
A000269	Door kit for use with MI Optidew. (Optidew dew-point sensor port adapter, PRT port adapter and 4 x ø19mm (0.75") adapters. Adapter tool included)
A000273	Polymer port adpt ø18.5mm (0.73") to ø3mm (0.19") (for Optidew probe)
A000290	M30x1 Molded polymer port adpt & blind stop (to be modified by customer)
A000290X	Polymer port adpt ø client specific & blind stop
A000291	Polymer port adpt for ø12mm (0.47") probe, blind stop (M30x1)
A000292	Polymer port adpt for ø13.5mm (0.53") probe, blind stop (M30x1)
A000293	Polymer port adpt for ø14mm (0.55") probe, blind stop (M30x1)
A000294	Polymer port adpt for ø15mm (0.59") probe, blind stop (M30x1)
A000295	Polymer port adpt for ø18.5mm (0.73") probe, blind stop (M30x1)
A000296	Polymer port adpt for ø19mm (0.75") probe, blind stop (M30x1)
A000297	Polymer port adpt for ø24mm (0.95") probe, blind stop (M30x1)
A000298	Polymer port adpt for ø25mm (0.98") probe, blind stop (M30x1)
A000200	ø18.5mm (0.73") Blind stop
A000265	Tool for changing the port adapters
Miscellaneous	
A000171	0.25kg (0.55lbs) desiccant (orange)
A000172	3kg (6.6lbs) desiccant (orange)
A000240	Drying module
A000242	Water bottle
A000243	PRT sensor
HT961T00	Control sensor
OCAL-TC	Transport Case for OptiCal and S904
S8K-REM-TSG	S8000 Remote guard for S904

Note: Custom-built calibration systems available covering the range from -100° C (-148° F) dew point (10 ppb_v) up to $+85^{\circ}$ C ($+176^{\circ}$ F) dew point. Please discuss your requirements with Michell Instruments' Technical Sales Department

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: OptiCal Order Codes_97161_V3_UK_0416

.



.


HG10 Order Codes

To construct the order code, select the relevant features from the tables below, to create a string: {Dry Air Generaton} + {Dew-Point Generator} + {Dew-Point Hygrometer} + {Temperature Test Chamber}

Ordering Example: PSD-2 + 240 + HG-10 + S4K-RC-232 + UNI + 110 PSD2, high performance pressure swing dryer with 220 to 260 V AC power, HG10 PC control interface, S4000 Remote Climatic with 90 to 260 V AC power, 100 liter temperature test chamber

Dry Air Generation - Pressure Swing Dryer

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}




Dew-Point Generator

To construct the order code, select the relevant feature from the table below, starting with the type, which is {Feature A} and then add on options to create a string: {Feature A}

		HG-10
Type {Feature A}		
Base Unit, HG10 - PC control interface, control & logging software, complete system integration, rack - 1925 x 600 x 800mm (75.7 x 23.6 x 31.5") (h x w x d), Measure -50 to +50°Cdp (-58 to +122°Fdp) / Range 1 to 95% RH)	HG-10	


Dew-Point Hygrometer

To construct the order code, select the relevant feature from the tables below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A} + {Feature B}



Temperature Test Chamber

To construct the order code, select the relevant feature from the table below, starting with the base model, which is {Feature A} and then add on options to create a string: {Feature A}



Options

Item	Product / Description
Compressor System	
CMP-10-240	Oil free air mini compressor (29 psig / 2 barg, 10 l/min for PSD2)
Sensor Manifold	
DCS-MAN	Sensor Manifold (Manufactured to suit the customer's sensors typically in anodized aluminum for RH probes or 316 SS for dew-point sensors Price available on request when sensors to be calibrated are fully defined)

Michell Instruments can supply temperature controlled test chambers in a variety of configurations and capacities from 35 to 200L (+). Please contact Michell Instruments to discuss exact requirements and to receive a formal quotation before placing an order.

Please note: Michell Instruments adopts a continuous development program which sometimes necessitates specification changes without notice. Please contact us for latest version. Issue No: HG10 Order Codes_97158_V3_UK_0316



Abbreviations

The following abbreviations are used in this catalog;

Abbreviation	Definition	Abbreviation	Definition
°C	Degrees Celsius	NVLAP	National Voluntary Laboratory
°F	Degrees Fahrenheit		Accreditation Program
AC	Alternating current	ppm _v	Parts per million (by volume)
ATEX	European hazardous area directive	ppm _w	Parts per million (by weight)
atm	94/9/EC Pressure unit (atmosphere)	PRT	Platinum resistance thermometer (typically type Pt100)
bar	Pressure unit (=100 kP or 0.987	psig	Pound(s) per square inch (gauge)
	atm)	RH	Relative humidity
СОМ	Common	RS232	Serial communications standard
CSA	Canadian Standards Authority	RTU	Remote Terminal Unit
dBA	Decibel (a-weighting)	scfh	Standard cubic feet per hour
dp	Dew point	SD	Storage Device card (memory card
EU	European Union		for storing datalog files)
FM	Factory Mutual	sec	Second(s)
fs	Full scale	TEC	Thermo-electric cooler
g/kg	Grams per kilogram	temp	Temperature
g/m³	Grams per cubic meter	UKAS	United Kingdom Accredition
GOST-K	General Safety and Quality System Standards for Kazakhstan	UL	Service Underwriters Laboratories (US)
GOST-R	General Safety and Quality System	USB	Universal Serial Bus
	Standards for Russia	V	Volts
HMI	Human Machine Interface	VA	Volt-ampere
Hz	Hertz	VCR	Vacuum Coupling Radiation fitting
IEC	International Electrotechnical Commission		
IECEx	International Electrotechnical Commission standard for equipment for use in explosive atmospheres		
lbs	Pound(s)		
LCD	Liquid crystal display		
LED	Light emitting diode		
mA	Milliampere		
max	Maximum		
min	Minute(s)		
mV	Millivolt(s)		
N/C	Normally closed		
N/0	Normally open		
NIST	National Institute of Standards and Technology (US)		
NI/min	Normal liters per minute		
No	Number		



NPL

National Physical Laboratory

Glossary

Absorption (of water vapor)

Retention (of water vapor) by penetration into the bulk of a material

Adsorption (of water vapor)

Retention (of water vapor) as a surface layer on a material

Condensation

Condensation occurs when a vapor is compressed or cooled to its dew point, at which point its state changes from gas to liquid. This is often manifested as liquid droplets on a solid surface which is cooler than the dew-point temperature of the vapor.

Contaminant

An undesirable particulate, liquid or vapor component in a sample gas.

Desiccant

Any substance which exerts a drying action by chemically absorbing water vapor

Humidity

The presence of water vapor in air or other gas

Hygrometer

Any instrument for measuring humidity

Hygrometry

The measurement of humidity is called hygrometry, derived from the Greek term 'hygros' meaning moist. Hygrometry is the subject of humidity measurement

Inert gas

Chemically nonreactive gas, such as nitrogen, helium, argon etc

Manifold

A sample chamber designed to accommodate multiple probes or sensors, for the purpose of exposing them to humidity controlled calibration air or gas.

Moisture

Refers to liquid water or water vapor in any form

Platinum Resistance Thermometer

A highly accurate type of resistance temperature sensor commonly used in instrumentation. Also known as an RTD, PRT or PT100

Probe

Part of the instrument that houses the sensor remotely from the main body of the instrument

Sensor

The active or sensing part of a measuring instrument



Glossary

Transmitter

Instrument which normally gives an electrical output (analog or digital) rather than a displayed result

Partial pressure (of water vapor)

The part of the overall pressure exerted by the water vapor component in a gas. Expressed in units of pressure such as Pascal (100 kPa = 1 bar)

Saturated vapor pressure

Maximum pressure of water vapor that can exist at a given temperature. Expressed in units of pressure such as Pascal (100 kPa = 1 bar)

Dew Point (or dew point temperature) (°Cdp or °Fdp)

The dew point is the temperature at which condensation occurs if a gas is cooled (at constant pressure). This is in effect, the temperature at which a gas becomes saturated in equilibrium with water vapor. Dew point relates directly and uniquely to the water vapor pressure

Frost point (or frost-point temperature)

The temperature at which ice forms on cooling a gas. This is, in effect the temperature at which air is saturated in equilibrium with ice. It is the exact counterpart to dew point (though values differ).

Confusion can arise from the fact that condensation formed below 0°C is not necessary ice. At temperatures down to -30°C there is a high likelihood that condensation will occur in liquid phase, known as super-cooled water. The condensation temperatures for water and ice differ in this temperature range for a gas of the same moisture content. Care must be taken when interpreting the measurements of condensation dew-point meters, to correctly determine the state of the condensate.

The term "dew point" is often used generally to include "frost point"."

Mixing Ratio

Mass of water vapor per unit mass of dry air with which it is associated. It is a dimensionless ratio, but is often expressed in grams of water per kilogram of dry gas (g.kg⁻¹) or in other units of mass.

For low levels of moisture content, this may be expressed in parts per million by weight, i.e. mass of water vapor per million parts of dry gas (ppm or ppm(w)).

Parts per million

The total quantity of water vapour present in a gas, expressed as a fraction of 1×10^6 . Abbreviated as "ppm", the unit can be in terms of total gas volume (ppm,), or molecular weight (ppm,). For actual vapour pressure; e (in Pascals), and total gas pressure; p (in Pascals):

p × 100000

Relative Humidity


The relative humidity of a gas expresses how much water vapour it contains in relation to the total amount of water vapour sustainable at that temperature. This is defined as: The ratio of the actual vapour pressure to the saturation vapour pressure over a plane liquid water surface at the same temperature, expressed as a percentage.

Although this is not a recognised abbreviation, the phrase "relative humidity" is commonly abbreviated


RH, as in "X% RH". For actual vapor pressure; e (in Pascals) and saturation vapor pressure; es (in Pascals):

RH (in %) =
$$\frac{e}{e_s} \times 100$$





Michell Instruments operates an extensive network of subsidiaries and distributors stretching across 56 countries. Service centres and calibration laboratories are located on three continents: North America, Europe and Asia.



Michell Instruments' Global Sales & Support Network

Michell Instruments Ltd 48 Lancaster Way Business Park, Ely, Cambridgeshire, CB6 3NW Tel: +44 (0) 1353 658000, Fax: +44 (0) 1353 658199, Email: uk.info@michell.com, Web: www.michell.com/uk

Michell Instruments Brasil Ltda Av. Henrique Valadares,69 Loja C - Centro Rio de Janeiro, RJ, 20231-030 Brasil Tel: [55] 21 3852 7831 / [55] 21 99695 8173, Email: br.info@michell.com, Web: www.michell.com/br

Michell Instruments (Shanghai) Co., Ltd Room 1007, Qilai Building, 889 Yishan Road, Shanghai, 200233, China Tel: (86) 21 5401 2255, Fax: (86) 21 5401 2085, Email: cn.info@michell.com, Web: www.michell.com.cn

Michell Instruments GmbH Max-Planck-Str. 14, 61381, Friedrichsdorf, Deutschland Tel: +49 (0) 6172 5917-0, Fax: +49 (0) 6172 591799, Email: de.info@michell.com, Web: www.michell.com/de

Michell Instruments SAS 2, Rue Jean Desparmet, Lyon, 69008, France Tel: +33 (0) 437 53 88 20, Fax: +33 (0) 437 53 88 21, Email: fr.info@michell.com, Web: www.michell.com/fr

Michell Italia Srl Via Magenta 77, Edificio 6, 20017, Rho, Milano, Italia Tel: +39-02-4047-194, Fax: +39-02-4001-0565, Email: it.info@michell.com, Web: www.michell.com/it

Michell Japan KK Musashino Center Building, 1-19-18 Nakacho, Musashino, Tokyo, 180-0006, Japan Tel: (81) 422 502 600, Fax: (86) 21 5401 2085, Email: info@michell-japan.co.jp, Web: www.michell-japan.co.jp

Michell Instruments Benelux BV Krombraak 11, 4906 CR Oosterhout, The Netherlands Tel: +31(0)162 680 471, Fax: +31(0)162 437 566, Email: nl.sales@michell.com, Web: www.michell.com/nl

Michell Instruments Inc 319 Newburyport Turnpike, Suite 207, Rowley, MA 01969, USA Tel: 978 484 0005, Fax: 978 843 7669, Email: us.info@michell.com, Web: www.michell.com/us



Humidity and Dew-Point Calibration — Instruments, Systems & Services © Michell Instruments 2016 V3.2 0716