

# Data Sheet O2S-FR-T2-18X Oxygen Sensors - Screw Fit Probe

## **FEATURES**

- Oxygen pressure range 2 mbar 3bar
- Zirconium dioxide (ZrO<sub>2</sub>) sensing elements
- Non-consumption technology
- Integral heating element
- No need for temperature stabilisation
- No reference gas required
- High accuracy
- Linear output signal
- Operates with external interface boards
- M18x1.5 screw mount




# **SPECIFICATIONS**

| Heater Voltage* Stand by       | $4.35V_{DC} \pm 0.1V_{DC} (1.85A)$<br>$2V_{DC} (0.85A)$ |
|--------------------------------|---|
| Pump resistance @ 700°C**      | < 6kΩ   |
| Permissible gas temperature    | -100 to 250°C   |
| Gas flow rate                  | 0 to 10 m/s   |
| Repetitive permissible accele  | ration 5 g  |
| Incidental permissible acceler | ration 30 g   |

<sup>\*</sup> It is important to measure the heater voltage as close to the sensor as possible due to voltage drops in the supply cable. Heater can also be operated with an equivalent a.c. or PWM signals.

## **ELECTRICAL CONNECTION**



For detailed information on the sensor operation please refer to the following application note: AN0043 Operation Principle and Construction of Zirconium Dioxide Oxygen Sensor.


<sup>\*\*</sup> The constant current source used in the pump circuit should be designed to drive a load of up to  $6k\Omega$ 



# **Data Sheet**

# O2S-FR-T2-18X Oxygen Sensors - Screw Fit Probe

## **OUTLINE DRAWING**



39-00-0041 (pins)

X = 28mm for O2S-FR-T2-18C

All dimensions in mm. Sensor lengths are approximate.



# **Data Sheet**

# O2S-FR-T2-18X Oxygen Sensors - Screw Fit Probe

## PERFORMANCE CHARACTERISTIC

| Characteristics                          | Min. | Тур.                       | Max. | Unit   |  |
|--|------|----------------------------|------|--------|--|
| Oxygen pressure range                    | 2    |                            | 3000 | - mbar |  |
| Accuracy                                 |      |                            | 5    |        |  |
| Internal operational temperature         |      | 700 (4.35V <sub>DC</sub> ) |      | °C     |  |
| Response time (10-90% step)              |      |                            | 4    |        |  |
| Warm up time (prior to sensor operation) |      |                            | 100  |        |  |
| Warm up time (from stand by)             |      |                            | 20   | S      |  |
| Output stabilisation time                |      | ~180                       |      |        |  |

## **ORDERING INFORMATION**

| Part number       | Housing                              | Termination                      |
|-------------------|--------------------------------------|----------------------------------|
| O2S-FR-T2-18A     |                                      | 0.15m Cable with Molex Connector |
| O2S-FR-T2-18A-002 | Probe with M18 x 1.5 nut<br>X = 55mm | 0.3m Cable with Molex Connector  |
| O2S-FR-T2-18A-003 |                                      | 1.1m Cable with Molex Connector  |
| O2S-FR-T2-18B     |                                      | 0.15m Cable with Molex Connector |
| O2S-FR-T2-18B-002 | Probe with M18 x 1.5 nut<br>X = 45mm | 0.3m Cable with Molex Connector  |
| O2S-FR-T2-18B-003 |                                      | 1.1m Cable with Molex Connector  |
| O2S-FR-T2-18C     |                                      | 0.15m Cable with Molex Connector |
| O2S-FR-T2-18C-002 | Probe with M18 x 1.5 nut $X = 28mm$  | 0.3m Cable with Molex Connector  |
| O2S-FR-T2-18C-003 |                                      | 1.1m Cable with Molex Connector  |

# WARNING

# **Personal Injury**

DO NOT USE these products as safety or Emergengy Stop devices or in any other application Where failure of the product could result in Personal injury.

Failure to comply with these instructions could Result in death or serious injury.

# **CAUTION**

Do not exceed maximum ratings and ensure sensor is operated in accordance with all requirements of AN0043 Failure to comply with these instructions may result in product damage.

It is the customer's responsibility to ensure that this product is suitable for use in their application. For techincal assistance or advice, please email us: info@sstsensing.com